



# Grandstream Networks, Inc.

HT812/HT814 Series

## **Administration Guide**



## HT812/HT814 – Administration Guide

The HT812/HT814 analog telephone adaptors (ATAs) provide transparent connectivity for analog phones and faxes to the world of internet voice. Connecting to any analog phone, fax or PBX, the HT812/HT814 is an effective and flexible solution for accessing internet-based telephone services and corporate intranet systems across established LAN and internet connections. This Grandstream Handy Tones are a new addition to the popular Handy Tone ATA product family. This manual will help you to learn how to operate and manage your HT812/HT814 analog telephone adaptors and make the best use of their many upgraded features including simple and quick installation, 3-way conferencing, direct IP-IP Calling, and new provisioning support among other features. The HT812/HT814 are very easy to manage and configure, and they are specifically designed to be an easy to use and affordable VoIP solution for both the residential user and the teleworker.

## PRODUCT OVERVIEW

The HT812/HT814 are 2/4 ports analog telephone adaptors (ATAs) that allow users to create a high-quality and manageable IP telephony solution for residential and office environments. Their ultra-compact size, voice quality, advanced VoIP functionality, security protection and auto provisioning options enable users to take advantage of VoIP on analog phones and enables service providers to offer high quality IP service. The HT812/HT814 are an ideal ATA s for individual use and for large scale commercial IP voice deployments since they permit small and medium businesses to create integrated IP and PSTN telephony systems that efficiently manage communication costs. HT812/HT814's inclusion of an integrated NAT router and dual 10/100/1000Mbps Ethernet WAN and LAN ports enables a shared broadband connection between multiple Ethernet devices as well as the extension of VoIP services to analog phones.

### Feature Highlights

The following table contains the major features of the HT812/HT814:


 <b>HT812 / HT814</b>	<ul style="list-style-type: none"><li>◦ Support 2 SIP profiles through 2 FXS ports for HT812 and 4 FXS port for HT814 and dual 10/100/1000Mbps Ethernet port for HT812</li><li>◦ Support 3-way voice conferencing.</li><li>◦ Support wide range of caller ID formats.</li><li>◦ Support advanced telephony features, including call transfer, call forward, call-waiting, do not disturb, message waiting indication, multi-language prompts, flexible dial plan and more.</li><li>◦ Support T.38 Fax for creating Fax-over-IP.</li><li>◦ TLS and SRTP security encryption technology to protect calls and accounts.</li><li>◦ Automated provisioning options include TR-069 and XML config files.</li><li>◦ Failover SIP server automatically switches to secondary server if main server loses connection.</li><li>◦ Use with Grandstream's UCM series of IP PBXs for Zero Configuration provisioning.</li><li>◦ GR-909 Line Testing Functionalities.</li></ul>

Table 1: HT812/HT814 Features at a Glance

### HT812/HT814 Technical Specifications

The following table resumes all the technical specifications including the protocols/standards supported, voice codecs, telephony features, languages and upgrade/provisioning settings for the HT812/HT814.

Interfaces	
<b>Telephone Interfaces</b>	Two (2) RJ11 FXS ports for HT812.
	Four (4) RJ11 FXS sports for HT814.
<b>Network Interface</b>	Two (2) 10/100/1000 Mbps Ethernet port (RJ45).
<b>LED Indicators</b>	POWER, LAN, WAN, PHONE1, PHONE2 for HT812.
	POWER, LAN, WAN, PHONE1, PHONE2, PHONE3, PHONE4 for HT814.
<b>Factory Reset Button</b>	Yes.
<b>Voice, Fax, Modem</b>	
<b>Telephony Features</b>	Caller ID display or block, call waiting, flash, blind or attended transfer, forward, hold, do not disturb, 3-way conference.
<b>Voice Codecs</b>	G.711 with Annex I (PLC) and Annex II (VAD/CNG), G.723.1, G.729A/B, G.722, G.726, iLBC, OPUS, dynamic jitter buffer, advanced line echo cancellation.
<b>Fax over IP</b>	T.38 compliant Group 3 Fax Relay up to 14.4kbps and auto-switch to G.711 for Fax Pass-through.

<b>Short/Long Haul</b>	For HT812: 3 REN, up to 1km on 24AWG line.
<b>Caller ID</b>	Bellcore Type 1 & 2, ETSI, BT, NTT, and DTMF-based CID.
<b>Disconnect Methods</b>	Busy Tone, Polarity Reversal/Wink, Loop Current.
<b>Signaling</b>	
<b>Network Protocols</b>	TCP/IP/UDP, RTP/RTCP, HTTP/HTTPS, FTP/FTPS, ARP/RARP, ICMP, DNS, DDNS, DHCP, NTP, TFTP, SSH, Telnet, STUN, SIP (RFC3261), SIP over TCP/TLS, SRTP, TR-069.
<b>QoS</b>	Layer 2 (802.1Q VLAN, SIP/RTP 802.1p) and Layer 3 (ToS, Diffserv, MPLS).
<b>DTMF Methods</b>	In-audio, RFC2833 and/or SIP INFO.
<b>Provisioning and Control</b>	HTTP, HTTPS, SSH, FTP, FTPS, Telnet, TFTP, TR-069, secure and automated provisioning using TR069, syslog.
<b>Security</b>	
<b>Media</b>	SRTP.
<b>Control</b>	TLS/SIPS/HTTPS/HTTP/SSH/Telnet.
<b>Management</b>	Syslog support, SSH, Telnet remote management using web browser.
<b>Physical</b>	
<b>Universal Power Supply</b>	Input: 100-240VAC, 50-60Hz Output: 12V/0.5A for HT812. Output: 12V/1A for HT814.
<b>Environmental</b>	Operational: 32° – 104°F or 0° – 40°C. Storage: 14° – 140°F or -10° – 60°C. Humidity: 10 – 90% Non-condensing.
<b>Dimensions and Weight</b>	Dimension : 28.5 x 130 x 90 mm (H x W x D). Weight: 353.33g for HT812 and for 423.5g for HT814.
<b>Compliance</b>	
<b>Compliance</b>	FCC/CE/RCM.

Table 2: HT812/HT814 Technical Specifications

GETTING STARTED

This chapter provides basic installation instructions including the list of the packaging contents and also information for obtaining the best performance with the HT812/HT814.

Equipment Packaging

The HT812/HT814 ATAs packages contain:




Figure 1: HT812 Package Contents




Figure 2: HT814 Package Contents

Check the package before installation. If you find anything missing, contact your system administrator.

## HT812/HT814 Ports Description

The following figure describes the different ports on the back panel of the HT812/HT814.




Figure 3: HT812 Back Panel

Figure 4: HT814 Back Panel



<b>Phone 1 &amp; 2 (HT812)</b>	Connects the analog phones / fax machines to the ATA using an RJ-11 telephone cable.
<b>Phone 1,2,3 &amp; 4 (HT814)</b>	
<b>WAN</b> 	Connects the ATA to your router, switch or modem using an Ethernet RJ45 network cable.
<b>LAN</b> 	Connects the ATA to your PC or switch using an Ethernet RJ45 network cable.
<b>DC Power</b>	Connects the ATA to PSU (12V – 0.5A for HT812) and (12V – 1A for HT814).
<b>Reset</b>	Factory reset button. Press for 7 seconds to reset factory default settings.

Table 3: HT812/HT814 Connectors Definitions

## Connecting HT812/HT814

The HT812/HT814 are designed for easy configuration and easy installation, to connect your HT812/HT814, please follow the steps below:

### Scenario 1: Connecting the HT812/HT814 using WAN Port

When connecting HT812/HT814 using the WAN port, they will act as simple DHCP Client.

1. Insert a standard RJ11 telephone cable into the phone ports and connect the other end of the telephone cable to a standard touch-tone analog telephone.
2. Connect the WAN port of the HT812/HT814 to a router, switch or modem using an Ethernet cable.
3. Insert the power adapter into the HT812/HT814 and connect it to a wall outlet and make sure to respect the technical specifications of the power adapter used.
4. Power, WAN and Phone LEDs will be solidly lit when the HT812/HT814 is ready for use.

### Scenario 2: Connecting the HT812/HT814 using LAN Port

When connecting the HT812/HT814 using the LAN port, they will act as a router and DHCP serving addresses, the devices connected with HT812/HT814 LAN will pull DHCP addresses from your HT812/HT814.

1. Insert a standard RJ11 telephone cable into the phone ports and connect the other end of the telephone cable to a standard touch-tone analog telephone.
2. Connect a computer or switch to the LAN port of the HT812/HT814 using an Ethernet Cable.
3. Insert the power adapter into the HT812/HT814 and connect it to a wall outlet and make sure to respect the technical specifications of the power adapter used.
4. Power, LAN and Phone LEDs will be solidly lit when the HT812/HT814 is ready for use.

Please make sure to enable NAT Router under Web GUI → Basic Settings → Device Mode.




Figure 5: Connecting the HT812/HT814

## HT812/HT814 LEDs Pattern

There are four (4) LED types that help you manage the status of your HT812/HT814.



Figure 6: HT812/HT814 LEDs Pattern

LED Lights	Status
<b>Power LED</b>	The Power LED lights up when the HT812/HT814 are powered on and it flashes when the HT812/HT814 is booting up.
<b>WAN LED</b>	The WAN LED lights up when the HT812/HT814 are connected to your network through the WAN port.
<b>LAN LED</b>	The LAN LED lights up when the HT812/HT814 are connected to your network through the LAN port.
<b>Phone LED 1&amp;2 (HT812)</b> <b>Phone LED 1,2,3 &amp; 4 (HT814)</b>	<p>The phone LEDs indicate status of the respective FXS port-phone on the back panel</p> <ul style="list-style-type: none"> <li>○ <b>OFF</b> – Unregistered</li> <li>○ <b>ON (Solid Blue)</b> – Registered and Available</li> <li>○ <b>Blinking every 500 ms</b> – Off-Hook / Busy</li> <li>○ <b>Slow blinking</b> – FXS LEDs indicates voicemail</li> </ul>

Table 4: HT812/HT814 LEDs Pattern Description

## CONFIGURATION GUIDE

The HT812/HT814 can be configured via one of two ways:

- The IVR voice prompt menu.
- The Web GUI embedded on the HT812/HT814 using PC's web browser.

### Obtain HT812/HT814 IP Address via Connected Analogue Phone

HT812/HT814 are by default configured to obtain the IP address from DHCP server where the unit is located. To know which IP address is assigned to your HT812/HT814, you should access to the "Interactive Voice Response Menu" of your adapter via the connected phone and check its IP address mode.

Please refer to the steps below to access the interactive voice response menu:

1. Use a telephone connected to phone ports (FXS) of your HT812/HT814.
2. Press \*\*\* (press the star key three times) to access the IVR menu and wait until you hear "Enter the menu option".
3. Press 02 and the current IP address will be announced.

### Understanding HT812/HT814 Interactive Voice Prompt Response Menu

The HT812/HT814 have a built-in voice prompt menu for simple device configuration which lists actions, commands, menu choices, and descriptions. The IVR menu works with any phone connected to the HT812/HT814.

Pick up the handset and dial \*\*\*\*\* to use the IVR menu.

Menu	Voice Prompt	Options
<b>main Menu</b>	"Enter a Menu Option"	Press <b>"#"</b> to return to the main menu  Enter 01-05, 07,10, 12-17,47 or 99 menu options
<b>01</b>	"DHCP Mode",  "Static IP Mode"  "PPPoE Mode"	Press <b>"9"</b> to toggle the selection  If using "Static IP Mode", configure the IP address information using menus 02 to 05.  If using "Dynamic IP Mode", all IP address information comes from the DHCP server automatically after reboot.  If using "PPPoE Mode", configure PPPoE Username and Password from web GUI to get IP from your ISP.
<b>02</b>	"IP Address" + IP address	The current WAN IP address is announced  If using "Static IP Mode", enter 12-digit new IP address. <b>You need to reboot your HT812/HT814 for the new IP address to take Effect.</b>
<b>03</b>	"Subnet" + IP address	Same as menu 02
<b>04</b>	"Gateway" + IP address	Same as menu 02
<b>05</b>	"DNS Server" + IP address	Same as menu 02
<b>07</b>	Preferred Vocoder	Press <b>"9"</b> to move to the next selection in the list:  <ul style="list-style-type: none"> <li>◦ PCM U / PCM A</li> <li>◦ iLBC</li> <li>◦ G-726</li> <li>◦ G-723</li> <li>◦ G-729</li> <li>◦ OPUS</li> <li>◦ G722</li> </ul>
<b>10</b>	"MAC Address"	Announces the MAC address of the unit.  <b>Note:</b> The device has two MAC addresses. One for the WAN port and one for the LAN port. The device MAC address announced is the address of LAN port.
<b>12</b>	WAN Port Web Access	Press <b>"9"</b> to toggle between <b>enable / disable</b> .  Default is disabled.
<b>13</b>	Firmware Server IP Address	Announces current Firmware Server IP address. Enter 12-digit new IP address.
<b>14</b>	Configuration Server IP Address	Announces current Config Server Path IP address. Enter 12-digit new IP address.
<b>15</b>	Upgrade Protocol	Upgrade protocol for firmware and configuration update. Press <b>"9"</b> to toggle between <b>TFTP / HTTP / FTP / FTPS</b> or <b>HTTPS</b> . Default is HTTPS.
<b>16</b>	Firmware Version	Announces Firmware version information.
<b>17</b>	Firmware Upgrade	Firmware upgrade mode. Press <b>"9"</b> to toggle among the following three options:  <ul style="list-style-type: none"> <li>◦ Always check</li> <li>◦ Check when pre/suffix changes</li> <li>◦ Never upgrade</li> </ul>
<b>20</b>	"Check Device Individual Certificate Information"	The users can now use the IVR system to obtain specific details about the device's certificate.
<b>47</b>	"Direct IP Calling"	Enter the target IP address to make a direct IP call, after dial tone. (See <i>"Make a Direct IP Call"</i> .)
<b>86</b>	Voice Mail	Access to your voice mails messages.
<b>99</b>	"RESET"	Press <b>"9"</b> to reboot the device  Enter MAC address to restore factory default setting  (See <b>Restore Factory Default Setting</b> section)
	"Invalid Entry"	Automatically returns to main menu
	"Device not registered"	This prompt will be played immediately after off hook If the device is not registered and the option "Outgoing Call without Registration" is in NO

Table 5: Voice Prompt Menu

## Five success tips when using the voice prompt

- “9” functions as the ENTER key in many cases to confirm or toggle an option.
- All entered digit sequences have known lengths – 2 digits for menu option and 12 digits for IP address. For IP address, add 0 before the digits if the digits are less than 3 (i.e. – 192.168.0.26 should be key in like 192168000026. No decimal is needed).
- Key entry cannot be deleted but the phone may prompt error once it is detected.
- Dial \*98 to announce the extension number of the port.

Please make sure to reboot the device after changing network settings (IP Address, Gateway, Subnet...) to apply the new configuration.

## Configuration via Web Browser

The HT812/HT814 embedded Web server responds to HTTP GET/POST requests. Embedded HTML pages allow a user to configure the HT812/HT814 through a web browser such as Google Chrome, Mozilla Firefox and Microsoft's IE.

- **Microsoft Internet Explorer:** version 10 or higher.
- **Google Chrome:** version 58.0.3 or higher.
- **Mozilla Firefox:** version 53.0.2 or higher.
- **Safari:** version 5.1.4 or higher.
- **Opera:** version 44.0.2 or higher.

## Accessing the Web UI

- **Via WAN port**

For the initial setup, the Web access is by default enabled when the device is using private IP and disabled when using public IP, and you cannot access the Web UI of your HT812/HT814 until it's enabled, the following steps will show you how to enable it via IVR.

1. Power your HT812/HT814 using PSU with the right specifications.
2. Connect your analog phone to phone ports (FXS) of your HT812/HT814.
3. Press \*\*\* (press the star key three times) to access the IVR menu and wait until you hear "Enter the menu option".
4. Press 12, the IVR menu will announce that the web access is disabled, press 9 to enable it.
5. Reboot your HT812/HT814 to apply the new settings.

Please refer to steps below if your HT812/HT814 is connected via WAN port:

1. You may check your HT812/HT814 IP address using the IVR on the connected phone.

Please see [Obtain the HT812/HT814 IP address via the connected analogue phone](#)

2. Open the web browser on your computer.
3. Enter the HT812/HT814's IP address in the address bar of the browser.
4. Enter the administrator's password to access the Web Configuration Menu.

**Note:** The computer must be connected to the same sub-network as the HT812/HT814. This can be easily done by connecting the computer to the same hub or switch as the HT812/HT814.

- **Via LAN port**

Please refer to steps below if your HT812/HT814 is connected via LAN port:

1. Power your HT812/HT814 using PSU with the right specifications.
2. Connect your computer or switch directly to your HT812/HT814 LAN port.
3. Open the web browser on your computer.
4. Enter the default LAN IP address (192.168.2.1) in the address bar of the browser.
5. Enter the administrator's password to access the Web Configuration Menu.
6. Make sure to reboot your device after changing your settings to apply the new configuration.

Please make sure that your computer has a valid IP address on the range 192.168.2.x so you can access the web GUI of your HT812/HT814.

## Web UI Access Level Management

There are three default passwords for the login page:

User Level	Password	Web Pages Allowed
End User Level	123	Only Status and Basic Settings
Administrator Level	admin	All pages
Viewer Level	viewer	Only checking. Not allowed to modify content.

The password is case-sensitive and must contain 8-20 characters, at least one number, one uppercase, and one lowercase letter. When changing any settings, always submit them by pressing Update or Apply button at the bottom of the page. After submitting the changes in all the Web GUI pages, if a reboot is required, the web page will prompt the user to reboot by


offering a reboot button on the web page.

### Saving the Configuration Changes

After users make changes to the configuration, pressing **Update** button will save but not apply the changes until **Apply** button is clicked. Users can instead directly press **Apply** button. When a reboot is required to apply changes, the web page will prompt the user to reboot by offering a reboot button on the web page.

### Changing Admin Level Password

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Advanced Settings** → **New Admin Password** and enter the new admin password.
5. Confirm the new admin password.
6. Press **Apply** at the bottom of the page to save your new settings.




The screenshot shows the 'Grandstream Device Configuration' web interface. At the top, there is a navigation bar with tabs: STATUS, BASIC SETTINGS, ADVANCED SETTINGS, PROFILE 1, PROFILE 2, and FXS PORTS. The 'ADVANCED SETTINGS' tab is selected. Below the navigation bar, the 'New Admin Password' form is displayed. It includes a text input field for the new password, a confirmation field, and a note: '(Must contain 8-20 characters, at least one number, one uppercase and lowercase letter. Purposely not displayed for security protection.)'. The 'Confirm Admin Password' field is also present.

Figure 7: Admin Level Password

### Changing User Level Password

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Basic Settings** → **New End User Password** and enter the new end-user password.
5. Confirm the new end-user password.
6. Press **Apply** at the bottom of the page to save your new settings.




The screenshot shows the 'Grandstream Device Configuration' web interface. At the top, there is a navigation bar with tabs: STATUS, BASIC SETTINGS, ADVANCED SETTINGS, PROFILE 1, PROFILE 2, and FXS PORTS. The 'BASIC SETTINGS' tab is selected. Below the navigation bar, the 'New End User Password' form is displayed. It includes a text input field for the new password, a confirmation field, and a note: '(Must contain 8-20 characters, at least one number, one uppercase and lowercase letter. Purposely not displayed for security protection.)'. The 'Confirm End User Password' field is also present.

Figure 8: User Level Password

### Changing Viewer Password

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Basic Settings** → **New Viewer Password** and enter the new viewer password.
5. Confirm the new viewer password.
6. Press **Apply** at the bottom of the page to save your new settings.



The screenshot shows the 'Grandstream Device Configuration' web interface. At the top, there is a navigation bar with tabs: STATUS, BASIC SETTINGS, ADVANCED SETTINGS, PROFILE 1, PROFILE 2, and FXS PORTS. The 'BASIC SETTINGS' tab is selected. Below the navigation bar, the 'New Viewer Password' form is displayed. It includes a text input field for the new password, a confirmation field, and a note: '(Must contain 8-20 characters, at least one number, one uppercase and lowercase letter. Purposely not displayed for security protection.)'. The 'Confirm Viewer Password' field is also present. The form is highlighted with a red border.

Figure 9: Viewer Level Password

### Changing HTTP Web Port

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Basic Settings** → **HTTP Web Port**.
5. Make sure that the **Web Access Mode** is set to **HTTP**.
6. Change the current port to your desired/new HTTP port. Ports accepted are in range [1-65535].
7. Press **Apply** at the bottom of the page to save your new settings.



Password: lowercase letter. Purposely not displayed for security protection.)  
 Confirm End User Password:   
 New Viewer  (Must contain 8-20 characters, at least one number, one uppercase and one lowercase letter. Purposely not displayed for security protection.)  
 Confirm Viewer Password:   
**Web/SSH Access:**  
 Web Session Timeout:  (1-60, default 10 minutes.)  
 Web Access Attempt Limit:  (1-10, default 5.)  
 Web Lockout Duration:  (0-60, default 15 minutes.)  
 Web Access Mode: ☐ HTTPS ☒ HTTP ☐ Disabled  
 HTTP Web Port:  (default is 80)  
 HTTPS Web Port:  (default is 443)

Figure 10: Web HTTP Port

## Web Configuration Pages Definitions

This section describes the options in the HT812/HT814 Web UI. As mentioned, you can log in as an administrator or an end user.

- **Status:** Displays the system info, network status, account status, and line options.
- **Basic Settings:** Configures the end user level password, IP address modes, web access, time zone settings and language.
- **Advanced Settings:** Configures networks, upgrading and provisioning, TR-069, security settings, date and time, syslog, audio settings, call settings and call progress tones.
- **Profile (1,2):** Configures the SIP Server, SIP Registration, NAT settings, call features, ring tones.
- **FXS Ports:** Configures SIP accounts settings, Off hook Auto-dial.

## Status Page Definitions

Status	
<b>MAC Address</b>	<p>Shows device ID in hexadecimal format. This is needed by network administrators for troubleshooting. The MAC address will be used for provisioning and can be found on the label on original box and on the label located on the bottom panel of the device.</p> <p><b>Note:</b> The device has two MAC addresses, one for the WAN port and one for the LAN port. The MAC address located on the bottom panel of the device is the MAC address of LAN port. The MAC address of WAN port is MAC address of LAN port + 1.</p> <p>Example: MAC Address: WAN – “00:0B:82:25:AF:32”, LAN – “00:0B:82:25:AF:31”.</p>
<b>WAN IPv4 Address</b>	Displays assigned IPv4 address.
<b>WAN IPv6 Address</b>	Displays assigned IPv6 address.
<b>VPN IPv4 Address</b>	Displays assigned OpenVPN IPv4 address.
<b>VPN IPv6 Address</b>	Displays assigned OpenVPN IPv6 address.
<b>Product Model</b>	Displays product model info. Default is <b>HT812</b> or <b>HT814</b> .
<b>Hardware Version</b>	Displays the hardware revision information and the part number.
<b>Software version</b>	<ul style="list-style-type: none"> <li>◦ <b>Program:</b> Specifies Program version. This is the main firmware release number, which is always used for identifying the software system of the HT812/HT814.</li> <li>◦ <b>Bootloader:</b> Specifies Boot version.</li> <li>◦ <b>Core:</b> Specifies Core version.</li> <li>◦ <b>Base:</b> Specifies Base version.</li> <li>◦ <b>CPE:</b> Specifies CPE version. CPE version is displayed only when HT812/HT814 is connected to an ACS using TR-069 protocol.</li> </ul>
<b>Software Status</b>	Indicates the current software status of the HT (Running or Stopped).
<b>System Up Time</b>	Indicates actual system time and uptime since last reboot.
<b>CPU Load</b>	Indicates CPU load (%)

<b>Network</b>	Indicates the Status of the Network cables connected to the LAN Port and the WAN Port.
<b>PPPoE Link Up</b>	Indicates PPPoE connection status.
<b>NAT</b>	Indicates type of NAT when it is configured.
<b>Port Status</b>	Displays relevant information regarding the FXS ports about their registration, current status and their appropriate User ID.
<b>Port Options</b>	Displays relevant information regarding the FXS ports about their DND and call forward features.
<b>CDR File</b>	<b>Download, Preview</b> . Or, <b>Delete</b> call history records from the web GUI. Only the last 1000 records will be available.
<b>SIP File</b>	<b>Download, Preview</b> or, <b>Delete</b> locally stored SIP trace. <b>Note: "Send SIP Log"</b> must be enabled to be able to capture the trace.
<b>Provision</b>	Displays provisioning status.
<b>Core Dump</b>	Provides generated core dump file if unit malfunctions. <b>Clean</b> will be displayed if no issues.

Table 6: Status Page Definitions

### Basic Settings Page Definitions

Basic Settings	
New End User Password	Configures user level password. Case sensitive and max. Length of 20 characters. <b>Note</b> : The new Password must contain 8-20 characters, at least one number, one uppercase, and a lowercase letter. Purposely not displayed for security reasons.
Confirm End User Password	Re-enter the end user password to confirm change user password on web GUI to avoid typo or mistakes.
New Viewer Password	Configures viewer-level password. Case sensitive and max. length of 20 characters. <b>Note</b> : The new Password must contain 8-20 characters, at least one number, one uppercase, and a lowercase letter. Purposely not displayed for security reasons.
Confirm Viewer Password	Re-enter the viewer password to confirm change viewer password on web GUI to avoid typo or mistakes.
Web/SSH Access	
Web Session Timeout	Configure timer to logout web session during idle. Default is 10 min. Range is 2-60 min.
Web Access Attempt Limit	Configure attempt limit before logout. Default is 5. Range is 1-10.
Web Lockout Duration	If login attempt failed 5 times, login would be locked out for the time length. (Default 15 mins. Range 1-15 min).
Web Access Mode	Allows users to choose the Web Access Mode between "HTTPS", "HTTP" and "Disabled". If "Disabled" is selected, web UI access will be disabled. By default, "HTTP" is selected.
HTTP Web Port	Customizes HTTP port used to access the HT801/HT802 web UI. Default is 80.
HTTPS Web Port	Customizes HTTPS port used to access the HT801/HT802 web UI. Default is 443.
Disable SSH	Enables/disables the SSH access. Default is No (enabled).
SSH Port	Allows users to self-configure SSH Port number. By default, the port number is 22.
SSH Idle Timeout	Configures SSH session timeout. [0 – 86400] seconds; Default is 0.
Disable Telnet	Enables/disables the Telnet access. Default is Yes (disabled).
Telnet Port	Allows users to self-configure Telnet Port number. By default, the port number is 23.
Security Controls for SSH/Telnet Access	Allows the user to choose the security control for SSH or Telnet Access, the options can be :  1. Only allow SSH private IP users to set system Pvalue. 2. Allow all SSH users to set system Pvalue. 3. Allow all SSH users to set any Pvalue. 4. Allow any user to set any Pvalue. 5. Prohibit setting Pvalue.  By default , it is set to "Allow any user to set any Pvalue".

	Enables / Disables the Web and SSH access through the WAN port. The available options are
WAN Side Web/SSH Access	<ul style="list-style-type: none"> <li>● <b>No</b>: No access to the web or SSH from any IP address on the WAN side.</li> <li>● <b>Yes</b>: Access for the Web GUI and SSH is enabled on the WAN side.</li> <li>● <b>Auto</b>: Only private IP could access the web or SSH on the WAN side.</li> </ul> <p>Default setting is <b>Auto</b>.</p>
Whitelist for WAN Side	<p>Users can configure the whitelist for WAN Side to be used for remote management.</p> <p>Multiple IPs are supported and need to be separated by “space”. Example: 192.168.5.222 192.168.5.223 192.168.7.0/24</p> <p>Note: If both blacklist and whitelist are not empty, the blacklist is processed first, followed by the whitelist.</p>
Blacklist for WAN Side	<p>Users can configure the blacklist for WAN Side to ban WAN side web access.</p> <p>Multiple IPs are supported and need to be separated by “space”. Example: 192.168.5.222 192.168.5.223 192.168.7.0/24</p> <p>Note: If both blacklist and whitelist are not empty, the blacklist is processed first, followed by the whitelist.</p>
Internet Protocol	<p>Selects one of the following IP protocol modes:</p> <ul style="list-style-type: none"> <li>● <b>IPv4 Only</b>: Enforce IPv4 protocol only.</li> <li>● <b>IPv6 Only</b>: Enforce IPv6 protocol only.</li> <li>● <b>Both, Prefer IPv4</b>: Enable both IPv4 and IPv6 and prefer IPv4.</li> <li>● <b>Both, prefer IPv6</b>: Enable both IPv4 and IPv6 and prefer IPv6.</li> </ul> <p>Note: Make sure to reboot the phone for the changes to take effect.</p>
IPv4 Address	Allows users to configure the appropriate network settings on the HT80x to obtain IPv4 address. Users could select “DHCP”, “Static IP” or “PPPoE”. By default, it is set to “DHCP”.
Dynamically assigned via DHCP	<p>All the field values for the static IP mode are not used (even though they are still saved in the flash memory.) The HT801/802 acquires its IP address from the first DHCP server it discovers from the LAN it is connected.</p> <ul style="list-style-type: none"> <li>● <b>DHCP hostname</b>: Specifies the name of the client. The name may or may not be qualified with the local domain name. This field is optional but may be required by ISP.</li> <li>● <b>DHCP domain name</b>: Specifies the domain name that client should use when resolving hostname via the Domain Name System.</li> <li>● <b>DHCP vendor class ID</b>: Exchanges vendor class ID by clients and servers to convey particular configuration or other identification information about a client. Default is HT8XX.</li> </ul>
Use PPPoE	<p>Set the PPPoE account settings. If selected, ATA attempt to establish a PPPoE session if any of the PPPoE fields is set.</p> <ul style="list-style-type: none"> <li>● <b>PPPoE account ID</b>: Defines the PPPoE username. Necessary if ISP requires you to use a PPPoE (Point to Point Protocol over Ethernet) connection.</li> <li>● <b>PPPoE password</b>: Specifies the PPPoE account password.</li> <li>● <b>PPPoE Service Name</b>: Defines PPPoE service name. If your ISP uses a service name for the PPPoE connection, enter the service name here. This field is optional. Default is blank.</li> </ul>
Preferred DNS server	Specifies preferred DNS server to use when DHCP or PPPoE are set.
Statically configured as IP address	Configure IP address, subnet Mask, default router IP address, 1st preferred DNS server, 2nd preferred DNS server. These fields are set to zero by default.
IPv6 Address	<p>Allows users to configure the appropriate network settings on the HT80x to obtain IPv6 address. Users could select “DHCP”, “Static IP”. By default, it is set to “DHCP”.</p> <ul style="list-style-type: none"> <li>● <b>DHCP mode</b>: all the field values for the static IP mode are not used (even though they are still saved in the flash memory.) The HT801/HT802 acquires its IP address from the first DHCP server it discovers from the LAN it is connected.</li> <li>● <b>Static IP mode</b>: configure IP address, 1st and 2nd DNS server, preferred DNS server. These fields are set to zero by default.</li> <li>● <b>Full Static</b>: When enabling the option full static, users need to specify the Static IPv6 and the IPv6 Prefix length.</li> <li>● <b>Prefix Static</b>: When enabling the option prefix static, users need to specify the IPv6 Prefix (64 bits).</li> </ul>
Enable Management Interface	Allows administrator to setup a Virtual Network Interface on top of the physical interface for device management. Default is No.
Management Access	Chooses whether to access using “Management Interface Only” (Default) Or “Both Service and Management Interfaces”
Enable SNMP Through Management Interface	This feature allows users to route SNMP packets through management interface. Default setting is No.
Enable TR-069 Through Management Interface	This feature allows users to route TR-069 packets through the management interface. Default setting is No.
Enable Syslog Through Management Interface	This feature allows users to route Syslog packets through the management interface. Default setting is No.
Management Interface IPv4 Address	<p>Configures Voice VLAN Type :</p> <ul style="list-style-type: none"> <li>● Default is <b>dynamically assigned via DHCP</b></li> </ul> <p>Or,</p> <ul style="list-style-type: none"> <li>● <b>statically configured</b> as:</li> </ul>

	<ul style="list-style-type: none"> <li>○ IP Address : Default is <b>192.168.100.100</b></li> </ul>
	<ul style="list-style-type: none"> <li>○ DNS Server 1 : Default is <b>0.0.0.0</b></li> <li>○ DNS Server 2 : Default is <b>0.0.0.0</b></li> <li>● <b>802.1Q/VLAN Tag</b> vlan tagging : [0 – 4094]; Default is 0</li> <li>● <b>802.1p priority value</b> : priority : [0 – 7]; Default is 0</li> </ul>
<b>Time Zone</b>	Selects time zone to define date/time on the device.
<b>Self-Defined Time Zone</b>	Allows users to define their own time zone.
<b>Allow DHCP server to set Time Zone</b>	Obtains time zone setting (offset) from a DHCP server using DHCP Option 2; it will override selected time zone. If set to “No”, the analogue adapter will use selected time zone even if provided by DHCP server. The Default setting is Yes.
<b>Language</b>	Configures the languages of the voice prompt and web interface, except Spanish that it is only in IVR. Available languages: English, Chinese, Traditional Chinese, Russian, Spanish IVR.
<b>NAT/DHCP Server Information &amp; Configuration</b>	
<b>Device Mode</b>	Controls whether the device is working in NAT router mode or Bridge mode. Save the setting and reboot prior to configuring the HT812/HT814.
<b>NAT maximum ports</b>	Defines the number of ports that can be managed while in NAT router mode. Range: 0 – 4096, default is 1024. Typically, one port per connection.
<b>NAT TCP timeout</b>	NAT TCP idle timeout in seconds. Connection will be closed after preconfigured, timeout if not refreshed. Range: 0 – 3600
<b>NAT UDP timeout</b>	NAT UDP idle timeout in seconds. Connection will be closed after preconfigured, timeout if not refreshed. Range: 0 – 3600, default is 300
<b>Uplink bandwidth</b>	Specifies the maximum uplink bandwidth permitted by the device. This function is disabled by default. The total bandwidth can be set as: 128K, 256K, 512K, 1M, 2M, 3M, 4M, 5M, 10M or 15M. The primary function of this setting is to limit the uplink bandwidth for the device internal system, signaling and NATed traffic. Example: When 512k is configured, there will be at least 512kbps limited for internal system, signaling and NATed traffic. Voice or RTP stream will never be limited.
<b>Downlink bandwidth</b>	Specifies the maximum downlink bandwidth permitted by the device. This function is disabled by default. The total bandwidth can be set as: 128K, 256K, 512K, 1M, 2M, 3M, 4M, 5M, 10M or 15M. The primary function of this setting is to limit the download bandwidth for the device internal system, signaling and NATed traffic. Example: if 128 is configured, there will be at least 128kbps limited for internal system, signaling and NATed traffic. Voice or RTP stream will never be limited.
<b>Enable UPnP support</b>	When set to “Yes”, the HT812/HT814 acts as an UPnP gateway for your UPnP enabled applications. <b>UPnP = “Universal Plug and Play”</b>
<b>Reply to ICMP on WAN port</b>	Default is No. When set to “Yes”, the HT812/HT814 responds to the PING command from other computers, but is also made vulnerable to DOS attacks.
<b>Cloned WAN MAC Addr</b>	This allows the user to change/set a specific MAC address on the WAN interface. <i>Note:</i> Set in Hex format
<b>LAN Port VLAN Feature Under Bridge Mode</b>	Allows users to configure the customized VLAN tag and priority value under switch mode. VLAN Tag range is 0-4094, the Priority Vlaue range is 0-7. The Default for both is 0
<b>Enable LAN DHCP</b>	When set to “Yes”, device will function as a simple router and LAN port will provide IP addresses to internal network. Connect the WAN port to ADSL/Cable modem or any other equipment that provides access to public Internet
<b>LAN DHCP Base IP</b>	Base IP Address for a LAN port. Default factory setting is 192.168.2.1. Note: When the device detects WAN IP is conflicting with LAN IP, the LAN base IP address will be changed based on the network mask — the effective subnet will be increased by 1. For example; 192.168.2.1 will be changed to 192.168.3.1 if net mask is 255.255.255.0. Then the device will reboot
<b>LAN DHCP Start IP</b>	Default value is 100. The last segment of IP address assigned to the HT812/HT814 in the LAN Network. Default configuration assigns IP address (to local network devices) starting from 192.168.2.100.
<b>LAN DHCP End IP</b>	Default value is 199. This parameter allows a user to limit the number of local network devices connected to the internal router. Default configuration assigns IP address (to devices connected to the LAN port) in a range from 192.168.2.100 up to 192.168.2.199.
<b>LAN Subnet Mask</b>	Sets the LAN subnet mask. Default value is 255.255.255.0

	Default value is 120 hrs (5 days). The length of time the IP address is assigned to the LAN.
DMZ IP	This function forwards all WAN IP traffic to a specific IP address if no matching port is used by HT812/HT814 or in the defined port forwarding.
Port Forwarding	Forwards a matching (TCP/UDP) port to a specific LAN IP address with a specific (TCP/UDP) port. Up to 8 rules are available.
Reset Type	<p>Gives the administrator the option to restore default configuration on the HT801/HT802. There are 3 types of factory reset:</p> <ul style="list-style-type: none"> <li>● <b>ISP Data Reset:</b> All ISP (Internet Service Provider) configuration which may affect the IP address will be reseted (including WAN static IP).</li> <li>● <b>VOIP Data Reset:</b> All VoIP related configuration (mainly everything located on FXS page).</li> <li>● <b>Full Reset:</b> Both VoIP and ISP related configuration at the same time.</li> </ul> <p><i>Note:</i> After you choose the reset type, you must click the reset button to take effect.</p>

Table 7: Basic Settings Page

## Advanced Settings Page Definitions

New Admin Password	Defines the administrator level password to access the Advanced Web Configuration page. This field is case sensitive. Only the administrator can configure the "Advanced Settings" page. Password field is purposely left blank for security reasons after clicking update and saved. <b>Note :</b> The new Password must contain 8-20 characters, at least one number, one uppercase, and a lowercase letter. Purposely not displayed for security reasons
Confirm Admin Password	Confirms the new admin password.
Disable User Level Web Access	Disable or enable User Level Web Access. Default is No.
Disable Viewer Level Web Access	Disable or enable Viewer Level Web Access Default is No.
Layer 2 QoS	Sets values for 802.1Q/VLAN Tag. Default is 0. Valid range is 0-4094. SIP 802.1p. Default is 0. Valid range is 0-7. RTP 802.1p. Default is 0. Valid range is 0-7.
Blacklist for WAN Side Port	It could be either port range or single port separated by a "," Example: "5000-6000, 7000".
STUN Server is	Configures IP address or domain name of STUN server. Only non-symmetric NAT routers work with STUN.
Keep-alive interval	Sends periodically a blank UDP packet to SIP server to keep the "ping hole" on the NAT router open. Default is 20 seconds.
Use STUN to detect network connectivity	Uses STUN keep-alive to detect WAN side network problems. If keep-alive request does not yield any response for configured number of times (minimum 3), the device will restart the TCP/IP stack. If the STUN server does not respond when the device boots up, the feature is disabled. Default setting is No.
Use DNS to detect network connectivity	Uses DNS to detect WAN side network problems. Default setting is "No".
Use ARP to detect network connectivity	Uses ARP to check the network connectivity. Default is "Yes".
Verify host when using HTTPS	Enables / disables the host verification when using HTTPS.
Upgrade via	Selects firmware upgrade/provisioning method: TFTP, HTTP, HTTPS, FTP or FTPS. Default is HTTPS.
Provision and upgrade to new Gen-2 certificate	Configures whether or not to upgrade to a new Gen-2 certificate, It is set to no upgrade by Default.
Firmware Server Path	Sets IP address or FQDN of firmware server. The URL of the server that hosts the firmware release. <b>Note:</b> You can specify the protocol used in the Firmware Server Path. (example: https://192.168.5.120), this will bypass the "Upgrade Via" method. Default is fm.grandstream.com/gs.
Config Server Path	Sets IP address or FQDN of configuration server. The URL of the server that hosts the configuration file to provision HT8xx. <b>Note:</b> You can specify the protocol used in the Config Server Path. (example: https://192.168.5.120), this will bypass the "Upgrade Via" method. Default is fm.grandstream.com/gs.
XML Config File Password	Decrypts XML configuration file when encrypted. The password used for encrypting the XML configuration file using OpenSSL.
HTTP/HTTPS FTP/FTPS Username	Enters username to authenticate with HTTP/HTTPS FTP/FTPS server.

HTTP/HTTPS FTP/FTPS Password	Enters password to authenticate with HTTP/HTTPS FTP/FTPS server.
Firmware File Prefix	Checks if firmware file is with matching prefix before downloading it. This field enables user to store different versions of firmware files in one directory on the firmware server.
Firmware File Postfix	Checks if firmware file is with matching postfix before downloading it. This field enables user to store different versions of firmware files in one directory on the firmware server.
Config File Prefix	Checks if configuration files are with matching prefix before downloading them. This field enables user to store different configuration files in one directory on the provisioning server.
Config File Postfix	Checks if configuration files are with matching postfix before downloading them. This field enables user to store different configuration files in one directory on the provisioning server.
Enable using tags in URL	Allows users to configure variables on the configuration server path to differentiate the directories on the server.
Always send HTTP Basic Authentication Information	Default is No. If set to Yes, The device will send configured user name and password within HTTP request before server sends authentication challenge.
Allow DHCP Option 66 or 160 to Override Server	Obtains configuration and upgrade server's information using options 66 from DHCP server. Note: If DHCP Option 66 is enabled, the HT8xx will attempt downloading the firmware file from the server URL provided by DHCP, even though Config Server Path is left blank. The server URL provided by DHCP can include authentication credentials using following format: "username:password@Provisioning_Server_IP".
Additional Override DHCP Option	Allows users to enable the Additional Override DHCP Option in Option 150. The default value is "None".
3CX Auto Provision	Sends multicast "SUBSCRIBE" message for provisioning at booting stage, used for PnP (Plug-and-Play) configuration. Default is Yes.
Automatic Upgrade	Specifies when the firmware upgrade process will be initiated; there are 4 options: <b>No:</b> The HT8xx will only do an upgrade once at boot up. <b>Check every X minutes:</b> User needs to specify a period in minutes. <b>Check every day:</b> User needs to specify the start hour and the end hour of the day (0-23). <b>Check every week:</b> User needs to specify "Day of the week (0-6)". (Day of week is starting from Sunday). Default is No.
Randomized Automatic Upgrade	Randomized Automatic Upgrade within the range of hours of the day or postpone the upgrade every X minute(s) by random 1 to X minute(s).
Always Check for New Firmware at Boot up	Configures the HT8xx to always search for the new firmware at boot up. During the boot stage, the HT8xx will contact the firmware upgrade server to search for a new firmware, when available it will start the upgrade process, otherwise it will boot normally.
Check New Firmware only when F/W pre/suffix changes	Configure the HT8xx to search for the new firmware when the firmware prefix / suffix changes. When this option is selected, the HT8xx will check for updates only when the pre/suffix has been changed.
Always Skip the Firmware Check	Configures the HT8xx to skip the firmware check, when this option is selected the HT8xx will always skip searching for a new firmware.
Configuration File Types Allowed	Allows users to configure provision configuration file type in xml file only or all file types.
Download and Process All Available Config Files	This feature allows users to download and process all available config files. By default, the device will provision the first available config in the order of cfgMAC > cfgMAC.xml > cfgMODEL.xml > and cfg.xml (corresponding to device-specific, model-specific, and global configs). If this option is enabled, the device will inverse the downloading process to cfg.xml > cfgMODEL.xml > cfgMAC.bin > cfgMAC.xml and add cfgMAC_override.xml. The following files will override the files that have already been loaded and processed. The default value is "No"
Disable SIP NOTIFY Authentication	Disables the SIP NOTIFY Authentication on the phone adapter. If set to "Yes", the phone adapter will not challenge NOTIFY with 401. The default setting is "No"
Authenticate Conf File	Authenticates configuration before being accepted. This protects the configuration from unauthorized modifications. Default is No.
Validate Server Certificates	This feature allows users to validate server certificates with our trusted list of TLS connections. The device needs to reboot after changing the setting. Default is enabled.
Trusted CA certificates A	Uses the certificate for Authentication if "Check Domain Certificates" is set to "Yes" under "Account"-> "SIP Settings".
Trusted CA certificates B	Uses the certificate for Authentication if "Check Domain Certificates" is set to "Yes" under "Account"-> "SIP Settings".
Load CA Certificates	This feature allows user to specify which certificate to trust when performing server authentication. <b>Build-in trusted :</b> (Default) Build-in trusted certificates <b>Custom trusted certificate:</b> Uploaded Certificates

	Default Value is New Root.
<b>SIP TLS Certificate</b>	Specifies SSL certificate used for SIP over TLS is in X.509 format. The HT8xx has built-in private key and SSL certificate. Maximum supported length is 4069.
<b>SIP TLS Private Key</b>	Specifies TLS private key used for SIP over TLS is in X.509 format. Maximum supported length is 4069.
<b>SIP TLS Private Key Password</b>	Specifies SSL Private key password used for SIP Transport in TLS/TCP.
<b>Custom Certificate (Private Key + Certificate)</b>	Allows users to update to the device their own certificate signed by a custom CA certificate to manage client authentication.
<b>Gen-2 EC private key</b>	Configures the Gen-2 Elliptic Curve Private Key, based on RFC 5915. The Max value length is 8192 characters.
<b>Enable TR-069</b>	Sets the phone adapter system to enable the “CPE WAN Management Protocol” (TR-069). Default setting is Yes. <b>Note:</b> New Parameters were added to the TR069 Data model starting from Firmware version 1.0.47.4
<b>TR-069 firewall rules</b>	Configures the TR-069 firewall rules , Value port range is 1-65535
<b>ACS URL</b>	Specifies URL of TR-069 Auto Configuration Servers (e.g., http://acs.mycompany.com), or IP address. Default setting is: “https://acs.gdms.cloud”
<b>ACS Username</b>	Enters username to authenticate to ACS.
<b>ACS Password</b>	Enters password to authenticate to ACS.
<b>Periodic Inform Enable</b>	Sends periodic inform packets to ACS. Default is Yes.
<b>Periodic Inform Interval</b>	Sets frequency that the inform packets will be sent out to ACS. Default is 86400 seconds.
<b>Connection Request Username</b>	Enters username for ACS to connect to the HT8xx.
<b>Connection Request Password</b>	Enters password for ACS to connect to the HT8xx.
<b>Connection Request Port</b>	Configures the TR-069 connection request port. The value range is 0 to 65535.Default is 7547
<b>CPE SSL Certificate</b>	Configures the Cert File for the phone adapter to connect to the ACS via SSL.
<b>CPE SSL Private Key</b>	Specifies the Cert Key for the phone adapter to connect to the ACS via SSL.
<b>Enable SNMP</b>	Default is No.
<b>SNMP Version</b>	Choose between (Version 1, Version 2c, or Version 3).
<b>SNMP Port</b>	Listening Port of SNMP daemon (Default 161).
<b>SNMP Trap IP Address</b>	IP address of trap destination. Up to 3 trap destinations are supported. Users should enter the IP addresses separated with comma (,).
<b>SNMP Trap port</b>	Port of Trap destination (Default 162)
<b>SNMP Trap Version</b>	Choose between (Version 1, Version 2c, or Version 3).
<b>SNMP Trap Interval</b>	Time interval between traps (Default is 5).
<b>SNMPv1/v2c Community</b>	Name of SNMPv1/v2c community.
<b>SNMPv1/v2c Trap Community</b>	Name of SNMPv1/v2c trap community.
<b>SNMPv3 Username</b>	Username for SNMPv3.
<b>SNMPv3 Security Level</b>	<b>noAuthUser:</b> Users with security level noAuthnoPriv and context name as noAuth. <b>authUser:</b> Users with security level authNoPriv and context name as auth. <b>privUser:</b> Users with security level authPriv and context name as priv.
<b>SNMPv3 Authentication Protocol</b>	Select the Authentication Protocol: “None” or “MD5” or “SHA.”
<b>SNMPv3 Privacy Protocol</b>	Select the Privacy Protocol: “None” or “AES/AES128” or “DES”.
<b>SNMPv3 Authentication Key</b>	Enter the Authentication Key.
<b>SNMPv3 Privacy Key</b>	Enter the Privacy Key.

SNMPv3 Tran Username	Username for SNMPv3 Tran.
SNMPv3 Trap Security Level	<b>no/authUser:</b> Users with security level no/authPriv and context name as no/auth. <b>authUser:</b> Users with security level authNoPriv and context name as auth. <b>privUser:</b> Users with security level authPriv and context name as priv.
SNMPv3 Trap Authentication Protocol	Select the Authentication Protocol: "None" or "MD5" or "SHA".
SNMPv3 Trap Privacy Protocol	Select the Privacy Protocol: "None" or "AES/AES128" or "DES".
SNMPv3 Trap Authentication Key	Enter the Trap Authentication Key.
SNMPv3 Trap Privacy Key	Enter the Trap Privacy Key.
Enable RADIUS Web Access Control	Default is No.
Action upon RADIUS Auth Server Error	Choose action upon RADIUS server error. Default is Authenticate Locally (Default Authenticate Locally)
RADIUS Auth Server Address	Address of RADIUS Auth server.
RADIUS Auth Server Port	Port of RADIUS Auth server.
RADIUS Shared Secret	Set RADIUS shared secret.
RADIUS VSA Vendor ID	Configure RADIUS VSA Vendor ID to match RADIUS server's configuration. Default is 42397 for Grandstream Networks Inc.
RADIUS VSA Access Level Attribute	Configure RADIUS VSA Access Level Attribute to match RADIUS server's configuration. Incorrect setting would cause Radius authenticate fail.
Enable DDNS	Allow users to use DDNS.
DDNS Server	Selects DDNS Server: dyndns, freedns.afraid.org, zoneedit.com, no-ip.com, oray.net. Default is dyndns.
DDNS Username	64 characters as Max String Length.
DDNS Password	64 characters as Max String Length.
DDNS Hostname	64 characters as Max String Length.
DDNS Hash	64 characters as Max String Length.
Enable OpenVPN®	Allow user to enable OpenVPN®. Default is No.
OpenVPN® Server Address	Specify the IP address or FQDN for the OpenVPN® Server.
OpenVPN® Port	Specify the listening port of the OpenVPN® server. Default is 1194
OpenVPN® Interface type	Specify the Interface type of OpenVPN® whether TAP or TUN. Default is TUN.
OpenVPN® Transport	Specify the Transport Type of OpenVPN® whether UDP or TCP. The default is UDP.
Enable OpenVPN® LZO Compression	Enable OpenVPN® LZO Compression. Default is Yes.
OpenVPN® Encryption	Select the OpenVPN® Encryption. Default is BF-CBC 128 bit (default key).
OpenVPN® Digest	Select the OpenVPN® Digest. Default is SHA1.
OpenVPN® CA	Specifies the OpenVPN® CA. Maximum Character Number is 8192.
OpenVPN® Certificate	Specifies the OpenVPN® Certificate. Maximum Character Number is 8192.
OpenVPN® Client Key	Specifies the Client Key. Maximum Character Number is 8192.
OpenVPN® Client Key Password	Configures the OpenVPN® Client Key Password. Maximum Length is 64.
OpenVPN® username	Configure the OpenVPN® username.
OpenVPN® password	Configure the OpenVPN® password
System Ring Cadence	Configuration option is set ring cadence on FXS port for all incoming calls. Syntax: c=on1/off1-on2/off2-on3/off3; (3 cadences maximum) Default is set to c=2000/4000; (US standards)
Call Progress Tones: Dial Tone Ringback Tone Busy Tone	Using these settings, users can configure tone frequencies and cadence according to their preference. By default, they are set to North American frequencies. Configure these settings with known values to avoid uncomfortable high pitch sounds. ON is the period of ringing ("On time" in 'ms') while OFF is the period of silence. In order to set a



Reorder Tone	continuous tone, OFF should be zero. Otherwise, it will ring ON ms and a pause of OFF ms and
Prompt Tone Conference Party Hangup Tone * Special Proceed Indication Tone Special Condition Tone	LRAI TONE. f1=350@-13, f2=440@-13, c=0/0; Syntax: f1=freq@vol, f2=freq@vol, c=on1/off1-on2/off2-on3/off3; [...] (Note: freq: 0 – 4000Hz; vol: -30 – 0dBm) * “Conference Party Hang-up Tone” will apply only if the “Special Feature” is set to “MTS”. Special Proceed Indication Tone: This feature allows user to configure the tone played when user goes offhook and there is voicemail on the subscribed mailbox. Need to set ‘MWI Tone’ to ‘Special Proceed Indication Tone’ to use this feature.
Prompt Tone Access Code	Key pattern to get Prompt Tone. Maximum 20 digits.
Lock Keypad Update	Configuration update via keypad (analog phone connected to FXS port keypad using IVR menu) is disabled if set to Yes.
Disable Voice Prompt	Voice prompt is disabled if set to Yes.
Disable Direct IP Call	Direct IP call is disabled if set to Yes.
Play Busy Tone When Account is unregistered	When this feature is set to Yes, device will play busy tone when the FXS port account is not registered, and the attached analog phone is offhook.
Blacklist for Incoming Calls	Allow users to block incoming calls from specific list of numbers. Maximum allow 10 SIP numbers and each number should be separated by a comma (',') in web UI. Other allowed characters are 0-9, comma (','), asterisk (*), pound sign (#) and plus sign (+).
NTP Server	Defines the URL or IP address of the NTP server. The ATA may obtain the date and time from the server. The default setting is “pool.ntp.org.”
Allow DHCP Option 42 to override NTP server	Defines whether DHCP Option 42 should override NTP server or not. When enabled, DHCP Option 42 will override the NTP server if it is set up on the LAN. The default setting is Yes.
DHCP Option 17 Enterprise Number	Configure the DHCP option 17 number. Default is 3561
CDR File Option	By default, the device will split the allowed memory for CDR file into 2 parts. Device will create the first CDR file which is half of the allowed size, when it is full, device will create the second file. When “CDR File Option” is set to Default “Keep”, device will keep the call records when both files are full, no more new record will be stored. When this feature is set to “Overwrite”, device will clear the first CDR file and start storing again. When the feature is disabled the device will not record any calls. The CDR file output will be available at Status page: [CDR File]
SIP File Option	By default, the device will split the allowed memory for SIP file into 2 parts. Device will create the first SIP file which is half of the allowed size, when it is full, device will create the second file. When “SIP File Option” is set to Default “Keep”, device will keep the call records when both files are full, no more new record will be stored. When this feature is set to “Overwrite”, device will clear the first SIP file and start storing again. The SIP file output will be available at Status page: [SIP File] Note: “Send SIP Log” must be enabled to be able to capture the trace.
Disable Weak TLS Cipher Suites	Allows users to disable weak ciphers DES/3DES and RC4, Symmetric Encryption SEED, Symmetric Authentication MD5, Protocol Version SSLv2/SSLv3 or Disable All of the Above Weak TLS Ciphers Suites. Default is No.
Minimum TLS Version	This feature allows customer to choose desired Minimum TLS Version. Choices are: Unlimited TLS 1.0 TLS 1.1 TLS 1.2 Default is Unlimited.
Maximum TLS Version	This feature allows customer to choose desired Maximum TLS Version. Choices are: Unlimited TLS 1.0 TLS 1.1 TLS 1.2 Default is Unlimited.
Syslog Protocol	If set to SSL/TLS, the syslog messages will be sent through secured TLS Protocol to syslog server. Default setting is UDP. Note: The CA certificate is required to connect with the TLS server A reboot is required to take effect.
Syslog Server	URL or IP address of syslog server. Note: A reboot is required to take effect.
Syslog Level	Select the HT8xx to report the log level. Default is NONE. The level is one of EXTRA DEBUG, DEBUG, INFO, WARNING or ERROR. Syslog messages are sent based on the following events: 1. product model/version on boot up (INFO level)

	2. NAT related info (INFO level)
	5. inbound and outbound calls (INFO level) 6. registration status change (INFO level) 7. negotiated codec (INFO level) 8. Ethernet link up (INFO level) 9. SLIC chip exception (WARNING and ERROR levels) 10. memory exception (ERROR level) extra syslog style (EXTRA DEBUG level) Note: A reboot is required to take effect.
Send SIP Log	Configures whether the SIP log will be included in the syslog messages. The default setting is No.
With Secret Key Information	Allows users to make packet capture including the secret key to decrypt the captured TLS packets. Default value is No.
Information Capture	Allows the user to start the Information capture process, which can be enabled with a reboot option every day at a specific time or disabled, Disabled by default.
Always Send HTTP Basic Authentication Information	If set to Yes, the device will send configured username and password within HTTP request without server sending authentication challenge.
Automatic Reboot	Default is No. When "Yes, reboot every day at hour" or "Yes, reboot every week at day" or "Yes, reboot every month at day" is checked, user can specify "Hour of the day (0-23)" or "Day of the week (0-6)" or "Day of the month (0-30)". Default time is Monday 1AM.
Download Device Configuration	Press Download button to download device configuration file to local computer. The filename is "config.txt". The file is plain text and not including password fields.
Download Device XML Configuration	Press Download to download device configuration file to local computer. The filename is "config.xml". The file will not include password fields.
Upload Firmware	Press Upload from local directory button to load the firmware file to the device from your computer. The firmware filename should be "ht80xfw.bin" (ht802fw.bin for HT802 for instance), "ht81xfw.bin" for HT812/HT814 or "ht818fw.bin" for HT818.
Upload Configuration	Press Upload from local directory button to load configuration file to the device from your computer. The configuration file should be an XML file (for instance: "config.xml"). Note: The field is not mandatory in the document but if available only device with specified MAC address will accept the configuration file.
Export Backup Configuration	Press Download button to export device backup configuration to computer. The output is "cfg<mac>_enc.xml" (where <mac> is the MAC address of the device). The file is encrypted and can be used on same device only.
Restore From Backup Configuration	Press Upload button to restore device configuration from previously exported backup configuration.
<i>E911/HELD Protocol:</i>	
Enable E911	Enable Enhanced 911 call. Default is disabled
HELD Protocol	Configure HELD transfer protocol. HTTP or HTTPS
HELD Synchronization Interval	The valid synchronization interval is between 30 to 1440 minutes. The synchronization is off when the interval is 0.
Location Server	Configure the primary Location Information Server (LIS) address
Location Server Username	Configure the user name of the primary Location Information Server (LIS)
Location Server Password	Configure the password of the primary Location Information Server (LIS)
Secondary Location Server	Configure the secondary Location Information Server (LIS) address
Secondary Location Server Username	Configure the user name of the secondary Location Information Server (LIS)
Secondary Location Server Password	Configure the password of the secondary Location Information Server (LIS)
HELD Location Types	Configure "locationType" element in the location request. "geodetic", "civic" and "location URI"
HELD NAI	Configure "locationType" element in the location request. "geodetic", "civic" and "location URI"
HELD Identity 1-10	HELD Identity
HELD Identity 1-10 Value	HELD Identity value
E911 Emergency Numbers	A user can configure multiple emergency numbers separated with the delimiter symbol ";".
Geolocation-Routing Header	If "Yes", E.911 INVITE message includes the "Geolocation-Routing" header with the value "Yes"

<b>Priority Header</b>	If "Yes". F.911 INVITE message includes the "Priority" header with the value "emergency"
------------------------	--

## Profiles Pages Definitions

<i>Profiles (1,2)</i>	
<b>Profile Active</b>	Activates / Deactivates the accounts. The FXS port configuration will not change if disabled, although the port will not be operational, in this state, there will be no dial tone when picking up the analog phone and making/receiving calls will not be possible.
<b>Primary SIP Server</b>	Configures SIP server IP address (Supports both IPv4 and IPv6 addresses) or domain name provided by VoIP service provider. (For example: sip.mycompany.com, IPv4:192.168.5.170, or IPv6: fe80::20b:82ff:fe75:211d). This is the primary SIP server used to send/receive SIP messages from/to HT81x.
<b>Failover SIP Server</b>	Defines failover SIP server IP address (Supports both IPv4 and IPv6 addresses) or domain name provided by VoIP service provider. (For example: sip.mycompany.com, IPv4:192.168.5.170, or IPv6 fe80::20b:82ff:fe75:211d). This server will be used if primary SIP server becomes unavailable.
<b>Prefer Primary SIP Server</b>	Selects to prefer primary SIP server. The account will register to primary Server if registration with Failover server expires. Default is No.
<b>Outbound Proxy</b>	Specifies IP address (Supports both IPv4 and IPv6 addresses) or domain name of outbound Proxy, or media gateway, or session border controller. (For example: proxy.myprovider.com, IPv4: 192.168.5.170, or IPv6: fe80::20b:82ff:fe75:211d). It's Used by HT818 for firewall or NAT penetration in different network environments. If symmetric NAT is detected, STUN will not work and only outbound proxy can correct the problem
<b>Backup Outbound Proxy</b>	Configures the backup outbound proxy to be used when the "Outbound Proxy" registration fails. (For example: proxy.myprovider.com, or IP address, if any: IPv4: 192.168.5.170/ IPv6: fe80::20b:82ff:fe75:211d). By default, this field is left empty.
<b>Prefer Primary Outbound Proxy</b>	If the user configures this option to "Yes", when the registration expires, the device will re-register via primary outbound proxy. By default, this option is disabled.
<b>From Domain</b>	allows users to add the actual domain name, it will override the from header.This is an optional configuration.
<b>Allow DHCP Option 120 (override SIP Server)</b>	Configures the HT81x to collect SIP server address from DHCP option 120. Default is No.
<b>SIP transport</b>	Selects transport protocol for SIP packets; UDP or TCP or TLS. Please make sure your SIP Server or network environment supports SIP over the selected transport method. Default is UDP.
<b>SIP URI Scheme When Using TLS</b>	Specifies if "sip" or "sips" will be used when TLS/TCP is selected for SIP Transport. The default setting is "sips".
<b>Use Actual Ephemeral Port in Contact with TCP/TLS</b>	Controls the port information in the Via header and Contact header. If set to "No", these port numbers will use the permanent listening port on the phone. Otherwise, they will use the ephemeral port for the connection. Default is No.
<b>NAT Traversal</b>	Indicates type of NAT for each account. This parameter configures whether the NAT traversal mechanism is activated. Users could select the mechanism from No, Keep-alive, STUN, UPnP. Default setting is No.
<b>DNS Mode</b>	Selects DNS mode to use for the client to look up server. One mode can be chosen. <b>A Record (Default):</b> resolves IP Address of target according to domain name. <b>SRV:</b> DNS SRV resource records indicate how to find services for various protocols. <b>NAPTR/SRV:</b> Naming Authority Pointer according to RFC 2915. <b>Use Configured IP:</b> If the SIP server is configured as domain name, device will not send DNS queries, but will use "Primary IP" or "Backup IP" to send SIP message if at least one of them is not empty. It will try to use "Primary IP" first, after 3 tries without any response, it will switch to "Backup IP 1", then "Backup IP 2", and then it will switch back to "Primary IP" after 3 retries.
<b>DNS SRV use Registered IP</b>	When the HT81x is registered using the second SRV record, making an outbound call, it will try the second SRV (registered IP) first. By default, this option is disabled and the DNS SRV will use first SRV instead of the registered IP.
<b>DNS SRV Failover Mode</b>	Configure the preferred IP mode when DNS Mode is SRV or NAPTR/SRV. • Default SIP request will always be sent to the address with the top priority based on the SRV query result, even if this address is different from the registered IP address. • Saved one until DNS TTL SIP request will always be sent to the registered IP address until DNS TTL expires or registered IP address is unreachable • Saved on until no response SIP request will always be sent to the registered IP address only until registered IP address is unreachable.
<b>Failback Timer</b>	When the primary SBC is up, device will send SIP requests to the primary SBC. If at any point device fails over to the secondary SBC, the SIP requests will stay on the failover SBC for the duration of the failback timer. When the timer expires, device will send SIP requests to the primary SBC, (in minutes. Default is 60 minutes, max 45 days).
<b>Register before DNS SRV Failover</b>	This feature is used to control whether the device need to initiate a new registration request (following existing DNS SRV fail-over mode) first and then direct the non-registration SIP request (INVITE) to the new successfully registered server or not.
<b>TEL URI</b>	Indicates E.164 number in "From" header by adding "User=Phone" parameter or using "Tel:" in SIP packets, if the HT81x has an assigned PSTN Number. <b>Disabled:</b> Use "SIP User ID" information in the Request-Line and "From" header.

	<b>User=Phone:</b> “User=Phone” parameter will be attached to the Request-Line and “From” header in the SIP request to the proxy server.
	Please consult your carrier before changing this parameter. Default is <i>DISABLED</i> .
<b>Use Request Routing ID in SIP INVITE Header</b>	If set to Yes, device will use the configured [Request URI Routing ID] in the SIP INVITE. This option is usually used under a SIP trunk account's configuration. Default is No.
<b>SIP Registration</b>	Controls whether the HT81x needs to send REGISTER messages to the proxy server. Default setting is Yes.
<b>Unregister on Reboot</b>	<p>Controls whether to clear SIP user's information by sending un-register request to the proxy server. The un-registration is performed by sending a REGISTER message with “Expires=0” parameter to the SIP server. This will unregister the SIP account under the concerned FXS page. Unregister on reboot option can be set to "No", "All" or "Instance".</p> <ol style="list-style-type: none"> <li><b>Set to "No":</b> If the "Unregister on reboot" option is set to "No", it means that the SIP user's information will not be cleared when the device reboots. In other words, the SIP account will remain registered with the server even after the device is rebooted.</li> <li><b>Set to "All":</b> If the "Unregister on reboot" option is set to "All", it means that all SIP accounts associated with the device will be unregistered when the device reboots. This option clears the SIP user's information for all the FXS ports on the device.</li> <li><b>Set to "Instance":</b> If the "Unregister on reboot" option is set to "Instance", it means that only the SIP account associated with the concerned FXS port will be unregistered when the device reboots. This option clears the SIP user's information for only the specific FXS port that is affected by the reboot.</li> </ol> <p>Default value is set to "No"</p>
<b>Outgoing Call Without Registration</b>	Enables the ability to place outgoing calls even if the account is not registered (if allowed by ITSP); device will not be able to receive incoming calls. Default is No.
<b>Register Expiration</b>	Refreshes registration periodically with specified SIP proxy (in minutes). Maximum interval is 65535 minutes (about 45 days). Default is 60 minutes (or 1 hour).
<b>Reregister Before Expiration</b>	Sends re-register request after specific time (in seconds) to renew registration before the previous registration expires.
<b>SIP Registration Failure Retry Wait Time</b>	Sends re-register request after specific time (in seconds) when registration process fails. Maximum interval is 3600 seconds (1 hour). Default is 20 seconds.
<b>SIP Registration Failure Retry Wait Time upon 403 Forbidden</b>	Sends re-register request after specific time (in seconds) when registration process fails with error 403 Forbidden. Maximum interval is 3600 seconds (1 hour). Default is 1200 seconds.
<b>Port Voltage Off upon no SIP Registration or SIP Registration Failure Delay Time of Port Voltage Off Timer Since Boot</b>	<p>Allows users to configure the timer of Port Voltage Off.</p> <p>For Port Voltage Off upon no SIP, the Valid Range is 0 to 60 with the Default value being 0 ( 0 means the port voltage is never turned off )</p>
<b>Enable SIP OPTIONS/NOTIFY Keep Alive</b>	Enables SIP OPTIONS or SIP NOTIFY to track account registration status so the ATA will send periodic OPTIONS/NOTIFY message to server to track the connection status with the server. Default setting is No.
<b>SIP OPTIONS/NOTIFY Keep Alive Interval</b>	Configures the time interval when the ATA send OPTIONS or NOTIFY message to SIP server. The default setting is 30 seconds, which means the ATA will send an OPTIONS/NOTIFY message to the server every 30 seconds. The default range is 1-64800.
<b>SIP OPTIONS Keep Alive Max Lost</b>	Defines the Number of max lost packets for SIP OPTIONS Keep Alive before re-registration. Between 3-10, default is 3.
<b>Layer 3 QoS</b>	<p>Defines Diff-Serv values for SIP and RTP.</p> <p>SIP DSCP (Diff-Serv value in decimal, 0-63, default 26)</p> <p>RTP DSCP (Diff-Serv value in decimal, 0-63, default 46)</p>
<b>Local SIP Port</b>	Defines local port to use by the HT81x for listening and transmitting SIP packets. Default value for FXS 1 is 5060 and 5062 for FXS 2.
<b>Local RTP Port</b>	Defines the local RTP-RTCP port pair the HT81x will listen and transmit. It is the HT81x RTP port for channel 0. The default value for FXS port is 5004
<b>Use Random SIP Port</b>	Controls whether to use configured or random SIP ports. This is usually necessary when multiple HT81x are behind the same NAT. Default is No.
<b>Use Random RTP Port</b>	Controls whether to use configured or random RTP ports. This is usually necessary when multiple HT81x are behind the same NAT. Default is No.

<b>Enable RTCP</b>	Allows users to enable RTCP. The default setting is “Yes”.
<b>Hold target Before Refer</b>	Allows user to hold or not hold the phone can before referring. The default setting is Yes.
<b>Refer-To Use Target Contact</b>	Includes target’s “Contact” header information in “Refer-To” header when using attended transfer. Default is No.
<b>Transfer on Conference Hang-up</b>	If set to “Yes”, when the phone hangs up as the conference initiator, the conference call will be transferred to the other parties so that other parties will remain in the conference call. Default setting is No.
<b>Disable Bellcore Style 3-Way Conference</b>	Gives the users the possibility of making conference calls by pressing “Flash” key, when it’s enabled by dialing *23 +second callee number. Default is No
<b>Remove OBP from Route Header</b>	Removes outbound proxy info in “Route” header when sending SIP packets. Default is No.
<b>Support SIP Instance ID</b>	Includes “SIP Instance ID” attribute to “Contact” header in REGISTER request as defined in IETF SIP outbound draft. Default is No.
<b>Validate Incoming SIP Messages</b>	Validates incoming SIP messages. Default is No.
<b>Check SIP User ID for Incoming INVITE</b>	Checks SIP User ID in the Request URI of incoming INVITE; if it doesn’t match the HT81x SIP User ID, the call will be rejected. Direct IP calling will also be disabled. Default is No.
<b>Authenticate Incoming INVITE</b>	Challenges the incoming INVITE for authentication with SIP 401 Unauthorized message. Default is No.
<b>Authenticate Server Certificate Domain</b>	Configures whether to validate the domain certificate when download the firmware/config file. If it is set to “Yes”, the phone will download the firmware/config file only from the legitimate server. The default setting is “No”.
<b>Authenticate server certificate chain</b>	Configures whether to validate the server certificate when download the firmware/config file. If it is set to “Yes”, the phone will download the firmware/config file only from the legitimate server. The default setting is “No”.
<b>Allow Incoming SIP Messages from SIP Proxy Only</b>	Checks SIP address of the Request URI in the incoming SIP message; if it doesn’t match the SIP server address of the account, the call will be rejected. Default is No.
<b>Use Privacy Header</b>	Determines if the “Privacy header” will be presented in the SIP INVITE message and if it includes the caller info in this header. If set to Default, it will add Privacy header unless special feature is Telkom SA or CBCOM. Default is Default.
<b>Use P-Preferred-Identity Header</b>	Specifies if the P-Preferred-Identity Header will be presented in the SIP INVITE message. If set to “default”, the P-Preferred-Identity Header will be omitted in SIP INVITE message when Telkom SA or CBCOM is active. If set to “Yes”, the P-Preferred- Identity Header will always be presented. If set to “No”, it will be omitted. Default setting is: Default.
<b>Use P-Access-Network-Info Header</b>	With this feature enabled, device will populate the WAN access node with IEE-802.11a, IEE-802.11b in P-Access-Network-Info SIP header.
<b>Use P-Emergency-Info Header</b>	This feature support of IEEE-48-addr and IEEE-EUI-64 in SIP header for emergency calls.
<b>Use P-Asserted-Identity Header</b>	When this feature is set to Yes, device will send P-Asserted-Identity Header on the SIP Invite. Default setting is No.
<b>SIP REGISTER Contact Header Uses</b>	Specifies which address (LAN or WAN address) the device will detect to use it in SIP Register Contact Header. Default is LAN Address.
<b>Caller ID Fetch Order</b>	Selects the Caller ID display order which need to be respected by the ATA. The available options are: <b>Auto:</b> When set to “Auto”, the ATA will look for the caller ID in the order of P-Asserted Identity Header, Remote-Party-ID Header and From Header in the incoming SIP INVITE. <b>Disabled:</b> When set to “Disabled”, all incoming calls are displayed with “Unavailable”. <b>From Header:</b> When set to “From Header”, the ATA will use the FROM header to display the caller ID.
<b>Allow SIP Factory Reset</b>	Allows to reset the devices directly through SIP Notify. If “Allow SIP Factory Reset” is set to “YES” under FXS PORT, then the ATA receives the NOTIFY from the SIP server with Event: reset, the HT should perform a factory reset after the authentication. The authentication in this case can be either with: The admin password if no SIP account is configured on the HT. With the credentials of the SIP account if configured on the ATA.

<b>Maximum</b>	
<b>SIP T1 Timeout</b>	Defines T1 timeout value. It is an estimate of the round-trip time between the client and server transactions. For example, the HT81x will attempt to send a request to a SIP server. The time it takes between sending out the request to the point of getting a response is the SIP T1 timer. If no response is received the timeout is increased to (2*T1) and then (4*T1). Request re-transmit retries would continue until a maximum amount of time defined by T2. Default is 0.5 seconds.
<b>SIP T2 Interval</b>	Identifies maximum retransmission interval for non-INVITE requests and INVITE responses. Retransmitting and doubling of T1 continues until it reaches T2 value. Default is 4 seconds.
<b>SIP Timer D</b>	Configures SIP Timer D defined in RFC3261. 0 – 64 seconds. Default is 0.
<b>DTMF Payload Type</b>	Defines payload type for DTMF using RFC2833.
<b>Preferred DTMF method (in order)</b>	Sorts DTMF methods (in-audio, via RTP (RFC2833) or via SIP INFO) by priority.
<b>Inband DTMF Duration</b>	allows users to config the Inband DTMF Duration and inter-duration. The default Duration is 100 ms. Valid range: 40-2000 ms. The default Inter-duration is 50 ms. Valid range: 40-2000 ms.
<b>Inband DTMF Tx Gain</b>	Allows users to configure the Inband DTMF Tx Gain. The Valid rand is -12 to 12 db. The Default value is 0db.
<b>DSP DTMF Detector Duration Threshold</b>	Allows users to config the DSP DTMF Detector Duration Threshold The default Duration is 30 ms. Valid range: 20-2000 ms. The default Inter-duration is 30 ms. Valid range: 20-2000 ms.
<b>Disable DTMF Negotiation</b>	Uses above DTMF order without negotiation. Default is No.
<b>Generate Continuous RFC2833 Events</b>	When enabled the RFC2833 events are generated until key is released. Default is No.
<b>Send Hook Flash Event</b>	Default is No. If set to yes, flash will be sent as DTMF event.
<b>Flash Digit Control</b>	When it set to YES it allows the user to perform some call setting when both channels are used while pressing: “Flash + 1” in order to hang up the current call and resume a call that was held. “Flash + 2” in order to hold the current call and resume a call that was held. “Flash + 3” in order to perform 3-way conference. “Flash + 4” in order to perform attended transfer. Note: Please refer to the user guide for detailed steps to perform above operations. More additional Digit events were added on the new firmware 1.0.43.10.
<b>Enable Call Waiting alert-info In 180 Ringing Response</b>	When set to Yes, Alert-Info header will be added in 180 Ringing for Call Waiting case
<b>Callee Flash to 3WC</b>	When this feature is set to Yes, device would be able to set up the 3-way conference call even when device is the callee in the second call. Default is No.
<b>Off Hook Auto Dial Delay</b>	Specifies the auto-dial delay after off hook.
<b>Proxy-Require</b>	Determines a SIP Extension to notify the SIP server that the HT81x is behind a NAT/Firewall.
<b>Use NAT IP</b>	Defines NAT IP address used in SIP/SDP messages. It should only be used if required by ITSP.
<b>SIP User-Agent</b>	This feature allows users to configure SIP User Agent. If not configured, device will use the default User Agent header.
<b>SIP User-Agent Postfix</b>	Configures the SIP User-Agent Postfix
<b>Add MAC in User-Agent</b>	This feature allows users to configure "User-Agent" in the SIP header field, when this feature is set to "No", "User-Agent" does not carry a MAC, when this feature is set "Yes except REGISTER", "User-Agent" in REGISTER SIP header field does not carry MAC but other SIP packet header fields carries MAC, when this feature is set to "Yes to all SIP", "User-Agent" in the SIP packet header field will carries the MAC.
<b>Use MAC Header</b>	This feature allows users to configure MAC Header in the SIP packet header field, when this feature is set to "No", the MAC header field is not carried in the SIP packet header field, when this feature is set to "REGISTER Only", the register packet header field carries the MAC header field but the remaining SIP packets do not carry MAC header fields, when this feature is set to "Yes to all SIP", the MAC header field is carried in the SIP data packet header field.
<b>RFC2543 Hold</b>	Toggles between RFC2543 hold and RFC3261 hold. RFC2543 hold allows to disable the hold music sent to the other side, in this case IP address (0.0.0.0) it will be sent in SDP instead of the IP address of the unit . RFC3261 (a line) will play the hold music to the other side.

<b>Disable Call</b>	
<b>Disable Call Waiting Caller ID</b>	Disables displaying caller ID when receiving a second incoming call. Default is No.
<b>Disable Call Waiting Tone</b>	Disables playing call waiting tone during active call when receiving a second incoming call. The CWCID will still be displayed. Default is No.
<b>Disable Connected Line ID</b>	Disables displaying the number of the person answering the phone. Default is No.
<b>Disable Receiver Off Hook Tone</b>	Enables / disables the warning to alert that the phone has been left off-hook for an extended period of time. Default is No.
<b>Disable Reminder Ring for On-Hold Call</b>	Enables playing the reminder ring. Default is No.
<b>Disable Reminder Ring for DND</b>	This feature allows user to disable reminder ring when FXS port is on DND mode. Default is Yes.
<b>Disable Visual MWI</b>	Disables use of visual message waiting indicator when there is an unread voicemail message. Default is No.
<b>Visual MWI Type</b>	Configures Visual WMI Type of signal sent to the analog phone to make it turn the lamp ON upon receiving a Voice mail. Check the phone's manual to find out what signal is supported, FSK (default) or Neon. <b>Note:</b> Some phones (depending on the model of the analog phone) when this feature is set to NEON it might auto ring (short beeps) when there is a voice mail available for that FXS port where it is connected.
<b>MWI Tone</b>	When set to Default, device will play Stutter Dial Tone when there is voicemail, if set to Special Proceed Indication Tone, device will play the configured special proceed indication tone upon user offhook when there is voicemail
<b>Do Not Escape '#' as %23 in SIP URI</b>	Replaces # by %23 in some special situations. Default is No.
<b>Disable Multiple m Line in SDP</b>	Sends only one m line in SDP, regardless of how many m fields are in the incoming SDP. Default is No.
<b>Ring Timeout</b>	Stops ringing when incoming call if not answered within a specific period of time. When set to 0 there will be no ringing timeout. Default is 60 seconds.
<b>Hunting Group Ring Timeout</b>	If call is not answered within this designated time period, the call will be forwarded to the next member of a Hunt Group. Default value is 20 seconds.
<b>Hunting Group Type</b>	Specifies Hunting Group Type, either "Linear" or "Circular". Linear style will sort the call to the lowest numbered available line, this is also called "serial hunting". Circular style will distribute the calls "round-robin". If a call is assigned to line 1, the next call goes to 2 and the next to 3. The succession throughout each of the lines continues even if one of the previous lines becomes available. When the end of the hunt group is reached, the hunting starts over at the first line. Lines are skipped if they are still busy on a previous call. Default is Circular.
<b>Delayed Call Forward Wait Time</b>	Forwards incoming call if not answered within a specific period of time when delayed call forward is activated locally (using *92 code). Default value is 20 seconds.
<b>No Key Entry Timeout</b>	Initiates the call within this time interval if no additional key entry during dialing stage. Default is 4 seconds.
<b>Early Dial</b>	Sends an early INVITE each time a key is pressed when a user dials a number. Otherwise, only one INVITE is sent after full number is dialed (user presses Dial Key or after "no key entry timeout" expires). This option should be used only if there is a SIP proxy is configured and supporting "484 Incomplete Address" responses. Otherwise, the call will likely be rejected by the proxy (with a 404 Not Found error). Default is No. This feature is NOT designed to work with and should NOT be enabled for direct IP-to-IP calling.
<b>Dial Plan Prefix</b>	Adds specified prefix to dialed number.
<b>Use # as Dial Key</b>	Treats "#" as the "Send" (or "Dial") key. If set to "No", this "#" key can be included as part of the dialed number. Default is Yes.
<b>Disable # as Redial Key</b>	Disables # to act as Redial key. If set to "Yes" and feature "Use # as Dial Key" set to Yes, the # key will act as dial key but not as redial key. Default is No.
<b>Dial Plan</b>	Dial Plan Rules: 1. Accept Digits: 1,2,3,4,5,6,7,8,9,0 , *, #, A,a,B,b,C,c,D,d 2. Grammar: x – any digit from 0-9; a. xx+ – at least 2 digits number; b. xx – exactly 2 digits number; c. ^ – exclude; d. . – wildcard, matches one or more characters

	<p>c. <b>[3-5]</b> – any digit of 3, 4, or 5;</p>
	<p>h. <b>&lt;=1&gt;</b> – add a leading 1 to all numbers dialed, vice versa will remove a 1 from the number dialed</p> <p>i. <b> </b> – or</p> <p>j. Flag <b>T</b> when adding a “T” at the end of the dial plan, the phone will wait for 3 seconds before dialing out. This gives users more flexibility on their dial plan setup. E.g. with dial plan 1XXT, phone will wait for 3 seconds to let user dial more than just 3 digits if needed. Originally the phone will dial out immediately after dialing the third digit.</p> <p>Example 1: {[369]11   1617xxxxxxx} –</p> <p>Allow 311, 611, 911, and any 10-digit numbers of leading digits 1617</p> <p>Example 2: {^1900x+   &lt;=1617&gt;xxxxxxx} –</p> <p>Block any number with leading digits 1900 and add prefix 1617 for any dialed 7-digit numbers</p> <p>Example 3: {1xxx[2-9]xxxxxx   &lt;2=011&gt;x+} –</p> <p>Allow any length of number with leading digit 2 and 10 digit-numbers of leading digit 1 and leading exchange number between 2 and 9; If leading digit is 2, replace leading digit 2 with 011 before dialing.</p> <p>1. Default: Outgoing – { x+   +x+   *x+   *xx*x+ }</p> <p>Example of a simple dial plan used in a Home/Office in the US:</p> <p>{ ^1900x.   &lt;=1617&gt;[2-9]xxxxxx   1[2-9]xx[2-9]xxxxxx   011[2-9]x.   [3469]11 }</p> <p>Explanation of example rule (reading from left to right):</p> <p>^1900x. – prevents dialing any number started with 1900</p> <p>&lt;=1617&gt;[2-9]xxxxxx – allows dialing to local area code (617) numbers by dialing 7 numbers and 1617 area code will be added automatically</p> <p>1[2-9]xx[2-9]xxxxxx – allows dialing to any US/Canada Number with 11 digits length</p> <p>011[2-9]x. – allows international calls starting with 011</p> <p>[3469]11 – allow dialing special and emergency numbers 311, 411, 611 and 911</p> <p>Note: In some cases, user wishes to dial strings such as *123 to activate voice mail or other application provided by service provider. In this case * should be predefined inside dial plan feature. An example dial plan will be: { *x+ } which allows the user to dial * followed by any length of numbers.</p>
<b>SUBSCRIBE for MWI</b>	Sends SUBSCRIBE periodically (depends on “Register Expiration” parameter) for message waiting indication. Default is No.
<b>Subscribe Retry Wait Time upon 403 Forbidden</b>	<p>This feature allows users to adjust the subscribe retry waiting time while it is rejected with 403 forbidden. Default is 0. Valid range: 0-10080 in minutes.</p> <p>Note: Not supported on HT818</p>
<b>Send Anonymous</b>	Sets “From”, “Privacy” and “P_Asserted_Identity” headers in outgoing INVITE message to “anonymous”, blocking caller ID. Default is No.
<b>Anonymous Call Rejection</b>	Rejects incoming calls with anonymous caller ID with “486 Busy here” message. Default is No.
<b>Special Feature</b>	Selects Soft switch vendors’ special requirements Examples of vendors: BroadSoft, CBCOM, RNK, Huawei, China Mobile, ZTE IMS, PhonePower, TELKOM SA, Vonage, Metaswitch, CenturyLink, MTS, Oi_BR, Telefonica, GIBTELECOM. The default is Standard.
<b>Enable Session Timer</b>	Disable the session timer when this option is set to “No”. By default, this option is enabled.
<b>Session Expiration</b>	Enables SIP sessions to be periodically “refreshed” via a SIP request (UPDATE, or re-INVITE). When the session interval expires, if there is no refresh via an UPDATE or re-INVITE message, the session will be terminated. Session Expiration is the time (in seconds) at which the session is considered timed out, if no successful session refresh transaction occurs beforehand. Valid range is 90-64800 seconds. Default is 180 seconds.
<b>Min-SE</b>	Defines Minimum session expiration (in seconds). Default is 90 seconds.
<b>Caller Request Timer</b>	Uses session timer when making outbound calls if remote party supports it. Valid range is 90-64800 seconds. Default is No.
<b>Callee Request Timer</b>	Uses session timer when receiving inbound calls with session timer request. Default is No.
<b>Force Timer</b>	Uses session timer even if the remote party does not support this feature. Selecting “No” will enable session timer only when the remote party supports it. To turn off Session Timer, select “No” for Caller and Callee Request Timer, and Force Timer. Default is No.
<b>UAC Specify Refresher</b>	<p>Specifies which end will act as refresher for outgoing calls.</p> <p>Default is Omit.</p> <p>UAC: The HandyTone acts as the refresher.</p> <p>UAS: Callee or proxy server act as the refresher.</p>
<b>UAS Specify Refresher</b>	<p>Specifies which end will act as refresher for incoming calls. Default is Omit.:</p> <p>UAS: The HandyTone acts as the refresher.</p> <p>UAC: Callee or proxy server act as the refresher.</p>
<b>Force INVITE</b>	Uses INVITE message to refresh the session timer. Default is No.
<b>When To Restart Session After Re-INVITE received</b>	Allows users to delay posting Media Change Event, it can be set to “Immediately” or to “After replying 200OK” The default value is “Immediately”.
<b>Enable 100rel</b>	Appends “100rel” attribute to the value of the required header of the initial signaling messages. Default is No.
<b>Add Auth Header on Initial REGISTER</b>	Adds “Authentication” header with blank “nonce” attribute in the initial SIP REGISTER request. Default is No.



Conference URI	Allows users to manually configure the conference URI.. The default is null.
Use First Matching Vocoder in 200OK SDP	Includes only the first matching vocoder in its 200OK response, otherwise it will include all matching vocoders in same order received in INVITE. Default is No.
Preferred Vocoder	Configures vocoders in a preference list (up to 8 preferred vocoders) that will be included with same order in SDP message. Vocoder types are G.711 A~/U-law, G.726-32, G.723, G.729, iLBC and OPUS
Voice Frames per TX	Transmits a specific number of voice frames per packet. Default is 2; increases to 10/20/32/64 for G711/G726/G723/other codecs respectively.
G723 Rate	Operates at specified encoding rate for G.723 vocoder. Available encoding rates are 6.3kbps or 5.3kbps. Default is 6.3kbps.
iLBC Frame Size	Specifies iLBC packet frame size (20ms or 30ms). Default is 20ms.
Disable OPUS Stereo in SDP	Disables OPUS stereo in SDP. Default is No.
iLBC Payload Type	Determines payload type for iLBC. Valid range is between 96 and 127. Default is 97.
OPUS Payload Type	Determines payload type for OPUS. Valid range is between 96 and 127. Default is 123.
VAD	Allows detecting the absence of audio and conserves bandwidth by preventing the transmission of “silent packets” over the network. Default is No.
Symmetric RTP	Changes the destination to send RTP packets to the source IP address and port of the inbound RTP packet last received by the device. Default is No.
Fax Mode	Specifies the fax mode: T.38 (Auto Detect) FoIP by default, or Pass-Through. If using Pass-through mode, select preference codec as PCMU or PCMA.
Re-Invite after Fax Tone Detected	Permits the unit to send out the re-INVITE for T.38 or Fax Pass Through if a fax tone is detected. Default is Enabled
Jitter Buffer Type	Selects jitter buffer type (Fixed or Adaptive) based on network conditions.
Jitter Buffer Length	<b>High</b> (initial 200ms, min 40ms, max 600ms) Note: not all vocoders can meet the high requirement. <b>Medium</b> (initial 100ms, min 20ms, max 200ms). <b>Low</b> (initial 50ms, min 10ms, max 100ms).
SRTP Mode	Selects SRTP mode to use (“Disabled”, “Enabled but not forced”, or “Enabled and forced”). Default is Disabled It uses SDP Security Description to exchange key. Please refer to <b>SDES</b> : <a href="https://tools.ietf.org/html/rfc4568">https://tools.ietf.org/html/rfc4568</a> <b>SRTP</b> : <a href="https://www.ietf.org/rfc/rfc3711.txt">https://www.ietf.org/rfc/rfc3711.txt</a>
SRTP Key Length	Allows users to select supported SRTP Key Length. the available values are :  1. AES 128&256 bit 2. AES 128 bit 3. AES 256 bit  Set to AES 128&256 bit By Default.
Crypto Life Time	Adds crypto life time header to SRTP packets. Default is Yes.
SLIC Setting	Depends on standard phone type (and location).
Caller ID Scheme	Selects the caller id scheme, for example: Bellcore/Telcordia, ETSI-FSK ...
DTMF Caller ID	Defines the start and stop tones (Default, A, B, C, D or #) to delimit CID.
Disable Unknown Caller ID	Disable analog phone’s caller ID when receiving a call with “Anonymous”, “unavailable” or “unknown” in FROM header and without “Display info”. Note: This relies also on analog phone’s design, some phones will still display “unknown” with this feature enabled. Default is No.
Replace Beginning ‘+’ with 00 in Caller ID	When this feature is set to Yes, device will replace the “+” sign at the beginning of a number in the FROM header. Default is No.
Polarity Reversal	Reverses the polarity upon call establishment and termination. Default is No.
Loop Current Disconnect	Allows the traditional PBX used with HT81x to apply this method for signaling call termination. Method initiates short voltage drop on the line when remote (VoIP) side disconnects an active call. Default is No.

<b>Play</b>	
<b>Current Disconnect</b>	Default is No.
<b>Loop Current Disconnect Duration</b>	Configures the duration of voltage drop described in topic above. HT81x support a duration range from 100 to 10000ms. Default value is 200.
<b>Enable Pulse Dialing</b>	Allow users to enable Pulse Dialing option under FXS Port. Default is No.
<b>Pulse Dialing Standard</b>	Allows users to use Swedish pulse dialing standard or New Zealand pulse dialing standard. Default is General Standard.
<b>Enable Hook Flash</b>	Enables the FLASH button to be used for terminating calls. Default is Yes.
<b>Hook Flash Timing</b>	Defines the time period when the cradle is pressed (Hook Flash) to simulate FLASH. To prevent unwanted activation of the Flash/Hold and automatic phone ring-back, adjust this time value. HT81x support a range from 40 to 2000 ms. Default values are 300 minimum and 1100 maximum.
<b>On Hook Timing</b>	Specifies the on-hook time for an on-hook event to be validated. HT81x support a range from 40 to 2000 ms. Default value is 400.
<b>Gain</b>	<p>Adjusts the voice path volume.</p> <ul style="list-style-type: none"> <li>Rx is a gain level for signals transmitted by FXS</li> <li>Tx is a gain level for signals received by FXS.</li> </ul> <p>Default = 0dB for both parameters. Loudest volume: +6dB Lowest volume: -6dB.</p> <p>User can adjust volume of call using the Rx gain level parameter and the Tx gain level parameter located on the FXS port configuration page.</p> <p>If call volume is too low when using the FXS port (ie. the ATA is at user site), adjust volume using the Rx gain level parameter under the FXS port configuration page.</p> <p>If voice volume is too low at the other end, user may increase the far end volume using the Tx gain level parameter under the FXS port configuration PAGE.</p>
<b>Disable Line Echo Canceller</b>	Disables the LEC per call base. Recommended for Fax/Data calls. Default is No.
<b>Disable Network Echo Suppressor</b>	Disables the NEC per call base. Recommended for Fax/Data calls. Default is No.
<b>Outgoing Call Duration Limit</b>	Defines the call duration limit for the outgoing calls. Default is 0 (No limit).
<b>Incoming Call Duration Limit</b>	allows users to configure the Incoming Call Duration Limit. Valid Range is 0 - 180 ( 0 is no limit ) Default value is 0.
<b>Ring Frequency</b>	Customizes ring frequency. Valid options: 20Hz – 25Hz. Default is 20Hz.
<b>Enable High Ring Power</b>	Configures a high ringing voltage output for the ATA.
<b>OnHOOK DC Feed Current</b>	This feature is used to adjust DC feed current.
<b>RFC2833 Events Count</b>	This feature allows users to customize the count of RFC2833 events. The Valid Value Range is between 2 and 10 , if it is set to 0 , it means continuous RFC2833 events are activated Default is 8.
<b>RFC2833 End Events Count</b>	This feature allows users to customize the count of RFC2833 end events. Default is 3.
<b>Distinctive Ring Tone</b>	<p>Customizes the Ring Tone 1 to 3 with associate caller ID: when selected, if caller ID is configured, then the device will ONLY use this ring tone when the incoming call is from the Caller ID. System Ring Tone is used for all other calls. When selected but no Caller ID is configured, the selected ring tone will be used for all incoming calls using the FXS port. Distinctive ring tones can be configured not only for matching a whole number, but also for matching prefixes. In this case the symbol “x+” will be used.</p> <p>For example: if configured as 617x+, Ring Tone 1 will be used in case of call arrived from the area code 617. Any other incoming call will ring using cadence defined in parameter System Ring Cadence located under Advanced Settings Configuration page.</p> <p>Note: If server supports Alert-Info header and standard ring tone set (Bellcore) or distinctive ring tone 1-10 is specified, then the ring tone in the Alert-Info header from server will be used. Bellcore rings and tones are independent from custom ring tones.</p> <p>The custom ring tones can also be specified by alert-info header, for example <i>Alert-Info: &lt;127.0.0.1&gt;; info=ring5</i></p>
<b>Ring tones</b>	<p>Configures the ring tone cadence preferences. User has 10 choices.</p> <p>The configuration, completed in Distinctive Ring Tones block in the same page, applies to ring tones cadences configured here.</p>
<b>Distinctive Call Waiting Tone</b>	Customizes the Call Waiting Tone 1 to 10 with associate caller ID: when selected, if caller ID is configured, then the device will ONLY use this call waiting tone when the incoming call waiting is from the Caller ID. When selected but no Caller ID is configured, the selected call waiting tone will be used for all incoming waiting calls using the FXS port. Distinctive Call Waiting Tones can be configured not only for matching a whole number, but also for matching prefixes. In this case symbol “x+” will be used.

For example: If configured as 617x+, Call Waiting Tone 1 will be used in case of waiting call arrived from the area

<b>Call Waiting Tones</b>	<p>This feature allows user to customize call waiting tone. User has 10 choices.</p> <p><i>Syntax: f1=val[,f2=val[,c=on1/off1[-on2/off2[-on3/off3]]]];</i></p> <p>(Frequencies are in (300, 3400) Hz and cadence on and off are in (0, 64000) ms)</p> <p>Note: The configuration, completed in Distinctive Call Waiting Tones block in the same page, applies to call waiting cadences configured here.</p> <p>Default is f1=440@-13,c=300/10000;</p>
<b>Call Features Settings</b>	
<b>Enable Call Features</b>	<p>When enabled, Do No Disturb, Call Forward and other call features can be used via the local feature codes on the phone. Otherwise, the ITSP feature codes will be used. Enable All will override all individual features enable setting. Default is Yes</p>
<b>Reset Call Features</b>	<p>Allows users to reset all call features configuration.</p> <p>Default is No</p>
<b>SRTP Feature</b>	<p>Allow users to customize the SRTP feature codes. Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable SRTP: Default is 16</li> <li>– Disable SRTP: Default is 17</li> </ul>
<b>SRTP per call Feature</b>	<ul style="list-style-type: none"> <li>– Enable SRTP per call: Default is 18</li> <li>– Disable SRTP per call: Default is 19</li> </ul>
<b>CID Feature</b>	<p>Allow users to customize the CID feature codes. Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable CID: Default is 31</li> <li>– Disable CID: Default is 30</li> </ul>
<b>CID per call Feature</b>	<ul style="list-style-type: none"> <li>– Enable CID per call: Default is 82</li> <li>– Disable CID per call: Default is 67</li> </ul>
<b>Direct IP Calling Feature</b>	<p>Allow users to customize the Direct IP feature code. Default is Yes</p> <ul style="list-style-type: none"> <li>– Direct IP Calling: Default is 47</li> </ul>
<b>CW Feature</b>	<p>Allow users to customize the CW feature codes. Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable CW: Default is 51</li> <li>– Disable CW: Default is 50</li> </ul>
<b>CW per call Feature</b>	<ul style="list-style-type: none"> <li>– Enable CW per call: Default is 71</li> <li>– Disable CW per call: Default is 70</li> </ul>
<b>Call Return Feature</b>	<p>Allow users to customize the Call Return feature code. Default is Yes</p> <ul style="list-style-type: none"> <li>– Call return: Default is 69</li> </ul>
<b>Unconditional Forward Feature</b>	<p>Allow users to customize the Unconditional Forward feature codes.</p> <p>Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable Unconditional Forward: Default is 72</li> <li>– Disable Unconditional Forward: Default is 73</li> </ul>
<b>Busy Forward Feature</b>	<p>Allow users to customize the Busy Forward feature codes. Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable Busy Forward: Default is 90</li> <li>– Disable Busy Forward: Default is 91</li> </ul>
<b>Delayed Forward Feature</b>	<p>Allow users to customize the Delayed Forward feature codes. Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable Delayed Forward: Default is 92</li> <li>– Disable Delayed Forward: Default is 93</li> </ul>
<b>Paging Feature</b>	<p>Allow users to customize the Paging feature code. Default is Yes</p> <ul style="list-style-type: none"> <li>– Paging: Default is 74</li> </ul>
<b>DND Feature</b>	<p>Allow users to customize the CW feature codes. Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable DND: Default is 78</li> <li>– Disable DND: Default is 79</li> </ul>
<b>Blind Transfer Feature</b>	<p>Allow users to customize the Blind Transfer feature code. Default is Yes</p> <ul style="list-style-type: none"> <li>– Enable Blind Transfer: Default is 87</li> </ul>
<b>Disable LEC per call Feature</b>	<p>Default is Yes</p> <ul style="list-style-type: none"> <li>– Disable LEC per call: Default is 03</li> </ul>
<b>Disable Bellcore Style 3-Way Conference</b>	<p>Default is No</p>
<b>Star Code 3WC Feature</b>	<p>Default is Yes</p> <ul style="list-style-type: none"> <li>– Star Code 3WC: Default is 23</li> </ul>
<b>Forced Codec Feature</b>	<p>Allow users to customize the Forced Codec feature code. Default is Yes</p> <ul style="list-style-type: none"> <li>– Forced Codec: Default is 02</li> </ul>
<b>PCMU Codec Feature</b>	<p>Default is Yes</p> <ul style="list-style-type: none"> <li>– PCMU Codec: Default is 7110</li> </ul>

<b>PCMA Codec</b>	Default is Yes
<b>G723 Codec Feature</b>	Default is Yes – G723 Codec: Default is 723
<b>G729 Codec Feature</b>	Default is Yes – G729 Codec: Default is 729
<b>iLBC Codec Feature</b>	Default is Yes – iLBC Codec: Default is 7201

## FXS Ports Page Definitions

FXS Ports	
<b>Port</b>	Display the port number
<b>SIP User ID</b>	Defines user account information provided by VoIP service provider (ITSP). Usually in the form of digit similar to phone number or actually a phone number.
<b>Authenticate ID</b>	Determines account authenticate ID provided by VoIP service provider (ITSP). Can be identical to or different from "SIP user ID".
<b>Password</b>	Specifies account password provided by VoIP service provider (ITSP) to register to SIP servers.
<b>Name</b>	Chooses a name to be associated to user.
<b>Profile ID</b>	Defines the profile ID for each port.
<b>Hunting Group</b>	<p>Configures hunting group feature on the specific port.</p> <p>For example: Port 1, 2, and 3 are members of the same Hunting Group. Port 1 is registered with a SIP account.</p> <p>Ports 2, and 3 are not registered. Ports 2 and 3 will be able to place outbound calls using the SIP account of port 1. Select appropriate value for Hunting Group feature.</p> <p>The original SIP account should be set to Active while the group members should be set to the port number of the Active Port.</p> <p>Example configuration of a Hunting group:</p> <p>FXS Port #1: SIP UserID and Authenticate ID entered, Hunting group set to "Active"</p> <p>FXS Port #2: SIP UserID and Authenticate ID left blank, Hunting Group set to "1"</p> <p>FXS Port #3: SIP UserID and Authenticate ID left blank, Hunting Group set to "1"</p> <p>FXS Port #4: SIP UserID and Authenticate ID entered, Hunting group set to "None"</p> <p>Hunting Group 1 contains ports 1, 2, 3. FXS port 4 is registered but it is not added to the Hunting Group 1.</p> <p><b>Note:</b> HT812/HT814 will use CID name from FXS port initiating the outgoing call if the "Name" field is entered for that specific port.</p>
<b>Request URI Routing ID</b>	If configured, device will route the incoming call to designated port by request URI user ID in SIP INVITE.
<b>Enable Port</b>	Enables / Disables the port.
<b>Off hook Auto-Dial</b>	Configures a User ID or extension number that is automatically dialed when off-hook. Only the user part of a SIP address needs to be entered here. The HT812/HT814 will automatically append the "@" and the host portion of the corresponding SIP address.

Table 10: FXS Ports

## Important Settings

### NAT Settings

If you plan to keep the Handy Tone within a private network behind a firewall, we recommend using STUN Server.

The following three settings are useful in the STUN Server scenario:

1. STUN Server (under advanced settings webpage) enter a STUN server IP (or FQDN) that you may have or look up a free public STUN server on the internet and enter it on this field. If using public IP, keep this field blank.
2. Use random SIP/RTP ports (under advanced settings webpage), this setting depends on your network settings. Generally, if you have multiple IP devices under the same network, it should be set to Yes. If using a public IP address, set this parameter to No.
3. NAT traversal (under the FXS web page) Set this to Yes when gateway is behind firewall on a private network.

### DTMF Methods

The HT812/HT814 support the following DTMF mode:

- DTMF via RTP (RFC2833)
- DTMF via SIP INFO

Set priority of DTMF methods according to your preference. This setting should be based on your server DTMF setting.

### Preferred Vocoder (Codec)

The HT812/HT814 support following voice codecs. On Profile pages, choose the order of your codecs:

- PCMU/A (or G711μ/a)
- G729 A/B
- G723.1
- G726
- iLBC
- OPUS
- G722

### Configuring HT812/HT814 Through Voice Prompts

As mentioned previously, The HT812/HT814 have a built-in voice prompt menu for simple device configuration. Please refer to "[Understanding HT812/HT814 Interactive Voice Prompt Response Menu](#)" for more information about IVR and how to access its menu.

#### ◦ DHCP MODE

Select voice menu option 01 to enable HT812/HT814 to use DHCP.

#### ◦ STATIC IP MODE

Select voice menu option 01 to enable HT812/HT814 to use STATIC IP mode, then use option 02, 03, 04, 05 to set up IP address, Subnet Mask, Gateway and DNS server respectively.

#### ◦ PPPOE MODE

Select voice menu option 01 to allow the HT812/HT814 to enable the PPPoE mode. PPPoE Username and Password should be configured from web GUI.

#### ◦ FIRMWARE SERVER IP ADDRESS

Select voice menu option 13 to configure the IP address of the firmware server.

#### ◦ CONFIGURATION SERVER IP ADDRESS

Select voice menu option 14 to configure the IP address of the configuration server.

#### ◦ UPGRADE PROTOCOL

Select the menu option 15 to choose firmware and configuration upgrade protocol between TFTP, FTP, FTPS, HTTP and HTTPS. Default is HTTPS.

#### ◦ FIRMWARE UPGRADE MODE

Select voice menu option 17 to choose firmware upgrade mode among the following three options:

1) Always check, 2) check when pre/suffix changes, and 3) never upgrade.

#### ◦ WAN PORT WEB ACCESS

Select voice menu option 12 to enable/disable web access from WAN port. Press 9 in this menu to toggle between enable / disable. Default is disabled.

### Configuration through a Central Server

The HT812/HT814 can be automatically configured from a central provisioning system.

When HT812/HT814 boots up, it will send TFTP, FTP/FTPS or HTTP/HTTPS requests to download configuration files, "cfg000b82xxxxx" and "cfg00082xxxxx.xml", where "000b82xxxxx" is the LAN MAC address of the HT812/HT814. If the download of "cfgxxxxxxx.xml" is not successful, the provision program will issue request a generic configuration file "cfg.xml". Configuration file name should be in lower case letters. The configuration data can be downloaded via TFTP, FTP/FTPS or HTTP/HTTPS from the central server. A service provider or an enterprise with large deployment of HT812/HT814 can easily manage the configuration and service provisioning of individual devices remotely from a central server.

Grandstream provides a central provisioning system GAPS (Grandstream Automated Provisioning System) to support automated configuration of Grandstream devices. GAPS uses HTTPS and other communication protocols to communicate with each individual Grandstream device for firmware upgrade, remote reboot, etc. Grandstream provides GAPS service to VoIP service providers. Use GAPS for either simple redirection or with certain special provisioning settings. At boot-up, Grandstream devices by default point to Grandstream provisioning server GAPS, based on the unique MAC address of each device, GAPS provision the devices with redirection settings so that they will be redirected to customer's TFTP or HTTP/HTTPS/FTP/FTPS server for further provisioning. Grandstream also provides configuration tools (Windows and Linux/Unix version) to facilitate the task of generating device configuration files.

The Grandstream configuration tools are free to end users. The configuration tools and configuration templates are available for download from <http://www.grandstream.com/support/tools>

the HT812/HT814 support 2 profiles which can be configured with 2 SIP accounts. Please refer to the following steps in order to register your accounts via web user interface

1. Access your HT812/HT814 web UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Profile (1 or 2)** pages.
5. In **Profile** tab, set the following:
  1. **Account Active** to **Yes**.
  2. **Primary SIP Server** field with your SIP server IP address or FQDN.
  3. **Failover SIP Server** with your Failover SIP Server IP address or FQDN. Leave empty if not available.
  4. **Prefer Primary SIP Server** to **No** or **Yes** depending on your configuration. Set to **No** if no Failover SIP Server is defined. If **Yes**, account will register to Primary SIP Server when failover registration expires.
  5. **Outbound Proxy**: Set your Outbound Proxy IP Address or FQDN. Leave empty if not available.
6. After configuring the SIP server and activating the profiles, you should access to **FXS Ports** page to register your accounts. In **FXS Ports** tab, set the following:
  1. **SIP User ID**: User account information, provided by VoIP service provider (ITSP). Usually in the form of digit similar to phone number or actually a phone number.
  2. **Authenticate ID**: SIP service subscriber's Authenticate ID used for authentication. Can be identical to or different from SIP User ID.
  3. **Authenticate Password**: SIP service subscriber's account password to register to SIP server of ITSP. For security reasons, the password will field will be shown as empty.
  4. **Name**: Any name to identify this specific user.
  5. Set **Enable Port** to **Yes**.

For more information, related to above options please refer to [Profile\(s\) settings](#) and [FXS Port Settings](#).

7. Press **Apply** at the bottom of the page to save your configuration.

**Grandstream Device Configuration**

**STATUS BASIC SETTINGS ADVANCED SETTINGS PROFILE 1 PROFILE 2 FXS PORTS**

**Profile Active:** ☐ No ☒ Yes

**Primary SIP Server:**  (e.g., sip.mycompany.com, or IP address)

**Failover SIP Server:**  (Optional, used when primary server no response)

**Prefer Primary SIP Server:** ☒ No ☐ Yes (yes - will register to Primary Server if Failover registration expires)

**Outbound Proxy:**  (e.g., proxy.myprovider.com, or IP address, if any)

Figure 11: SIP Profiles Settings

**Grandstream Device Configuration**

**STATUS BASIC SETTINGS ADVANCED SETTINGS PROFILE 1 PROFILE 2 FXS PORTS**

**User Settings**

Port	SIP User ID	Authenticate ID	Password	Name	Profile ID	Hunting Group	Request URI	Routing ID	Enable Port
1	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes
2	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes
3	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes
4	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	Profile 1 ▼	None ▼	<input type="text"/>	<input type="text"/>	<input type="radio"/> No <input checked="" type="radio"/> Yes

**Port Offhook Auto-dial**

1

2

3

4

All Rights Reserved Grandstream Networks, Inc. 2006-2017

Figure 12: SIP Accounts settings

After applying your configuration, your account will register to your SIP Server, you can verify if it has been correctly registered with your SIP server from your HT812/HT814 web interface under **Status → Port Status → Registration** (If it displays **Registered**, it means that your account is fully registered, otherwise it will display **Not Registered** so in this case you must double check the settings or contact your provider).

**WAN IPv4 Address:** 192.168.5.163  
**WAN IPv6 Address:**  
**Product Model:** HT814  
**Serial Number:**  
**Hardware Version:** V1.6A Part Number -- 9610004916A  
**Software Version:** Program -- 1.0.13.7 Bootloader -- 1.0.13.1 Core -- 1.0.13.1 Base -- 1.0.13.7  
CPE -- 0.19.7.10  
**Software Status:** Running Mem: 22840  
**System Up Time:** 11:39:53 up 3 min  
**CPU Load:** 0%  
**Network Cable Status:** WAN -- Up 100Mbps Full LAN -- Down 10Mbps Half  
**PPPoE Link Up:** Disabled  
**NAT:** Unknown NAT  
**Port Status:**

Port	Hook	User ID	Registration
FXS 1	On Hook	1001	Registered
FXS 2	On Hook		Not Registered
FXS 3	On Hook		Not Registered
FXS 4	On Hook		Not Registered

  
**Port Options:**

Port	DND	Forward	Busy Forward	Delayed Forward	CID	Call Waiting	SRTP
FXS 1	No				Yes	Yes	No
FXS 2	No				Yes	Yes	No
FXS 3	No				Yes	Yes	No
FXS 4	No				Yes	Yes	No

  
**CDR File:** [Download](#) [Preview](#) [Delete](#)  
**SIP File:** [Download](#) [Preview](#) [Delete](#)  
**Provision:** Not running. Last status : Downloading file from url.  
**Core Dump:** Clean

All Rights Reserved Grandstream Networks, Inc. 2006-2019

Figure 13: Accounts Status

When all the FXS ports are registered, the simultaneous rings will have one second delay between each ring on each phone.

## Call Features

The HT812/HT814 support all the traditional and advanced telephony features.

Key	Call Features
<b>*02</b>	<b>Forcing a Codec</b> (per call) *027110 (PCMU), *027111 (PCMA), *02723 (G723), *02729 (G729), *027201 (iLBC), *02722 (G722).
<b>*03</b>	<b>Disable LEC</b> (per call) Dial "**03" + " number".  <b>No</b> dial tone is played in the middle.
<b>*16</b>	<b>Enable SRTP</b>
<b>*17</b>	<b>Disable SRTP</b>
<b>*30</b>	<b>Block Caller ID</b> (for all subsequent calls)
<b>*31</b>	<b>Send Caller ID</b> (for all subsequent calls)
<b>*47</b>	<b>Direct IP Calling.</b> Dial "**47" + "IP address". <b>No</b> dial tone is played in the middle.
<b>*50</b>	<b>Disable Call Waiting</b> (for all subsequent calls)
<b>*51</b>	<b>Enable Call Waiting</b> (for all subsequent calls)
<b>*67</b>	<b>Block Caller ID (per call).</b> Dial "**67" + " number". <b>No</b> dial tone is played in the middle.
<b>*82</b>	<b>Send Caller ID (per call).</b> Dial "**82" + " number". <b>No</b> dial tone is played in the middle.
<b>*69</b>	<b>Call Return Service:</b> Dial *69 and the phone will dial the last incoming phone number received.
<b>*70</b>	<b>Disable Call Waiting (per call).</b> Dial "**70" + " number". <b>No</b> dial tone is played in the middle.
<b>*71</b>	<b>Enable Call Waiting (per call).</b> Dial "**71" + " number". <b>No</b> dial tone is played in the middle
<b>*72</b>	<b>Unconditional Call Forward:</b> Dial "**72" and then the forwarding number followed by "#". Wait for dial tone and hang up. (dial tone indicates successful forward)
<b>*73</b>	<b>Cancel Unconditional Call Forward.</b> To cancel "Unconditional Call Forward", dial "**73", wait for dial tone, then hang up.
<b>*74</b>	<b>Enable Paging Call:</b> Dial "**74" and then the destination phone number you want to page.
<b>*78</b>	<b>Enable Do Not Disturb (DND):</b> When enabled all incoming calls are rejected.
<b>*79</b>	<b>Disable Do Not Disturb (DND):</b> When disabled, incoming calls are accepted.

Key	Call Features
*90	<b>Busy Call Forward:</b> Dial "*90" and then the forwarding number followed by "#". Wait for dial tone then hang up.
*91	<b>Cancel Busy Call Forward.</b> To cancel "Busy Call Forward", dial "*91", wait for dial tone, then hang up.
*92	<b>Delayed Call Forward.</b> Dial "*92" and then the forwarding number followed by "#". Wait for dial tone then hang up.
*93	<b>Cancel Delayed Call Forward.</b> To cancel Delayed Call Forward, dial "*93", wait for dial tone, then hang up
Flash / Hook	Toggles between active call and incoming call (call waiting tone). If not in conversation, flash/hook will switch to a new channel for a new call.
#	Pressing pound sign will serve as Re-Dial key.

Table 11: HT812/HT814 Call Features

## Rebooting HT812/HT814 from Remote

Press "Reboot" button at the bottom of the configuration menu to reboot the ATA remotely. The web browser will then display a message window to confirm that reboot is underway. Wait 30 seconds to log in again.

## UPGRADING AND PROVISIONING

The HT812/HT814 can be upgraded via TFTP/FTP/FTPS/HTTP/HTTPS by configuring the URL/IP Address for the TFTP/FTP/FTPS/HTTP/HTTPS server and selecting a download method. Configure a valid URL for TFTP or FTP/FTPS or HTTP/HTTPS (default is HTTPS); the server name can be FQDN or IP address.

### Examples of valid URLs:

firmware.grandstream.com

fw.ipvideotalk.com/gs

## Firmware Upgrade procedure

Please follow below steps in order to upgrade the firmware version of your HT812/HT814:

1. Access your HT812/HT814 UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Advanced Settings** → **Firmware Upgrade and Provisioning** page, and enter the IP address or the FQDN for the upgrade server in "**Firmware Server Path**" field and choose to upgrade via **TFTP** or **HTTP/HTTPS** or **FTP/FTPS**.
5. Make sure to check "**Always Check for New Firmware**".
6. Update the change by clicking the "**Apply**" button at the bottom of the page. Then "**Reboot**" or power cycle the HT812/HT814 to update the new firmware.

Firmware Upgrade and Provisioning:
Upgrade Via
☐ TFTP
☐ HTTP
☒ HTTPS
☐ FTP
☐ FTPS

Firmware Server Path:

Config Server Path:

XML Config File Password:

HTTP/HTTPS/FTP/FTPS User Name:

HTTP/HTTPS/FTP/FTPS Password:

Firmware File Prefix: 
Firmware File Postfix:

Config File Prefix: 
Config File Postfix:

Allow DHCP Option 66 or 160 to override server:
☐ No
☒ Yes

3CX Auto Provision:
☐ No
☒ Yes

Automatic Upgrade:
☒ No
☐ Yes, every  minutes(30-5256000).
☐ Yes, daily at start hour  (0-23), at end hour  (0-23).
☐ Yes, weekly on day  (0-6).

Randomized Automatic Upgrade:
☒ No
☐ Yes

☒ Always Check for New Firmware at Boot up
☐ Check New Firmware only when F/W pre/suffix changes
☐ Always Skip the Firmware Check

Figure 14: Firmware Upgrade Page

## Upgrading via Local Directory

1. Download the firmware file from Grandstream web site
2. Unzip it and copy the file in to a folder in your PC
3. From the HT812/HT814 web interface (Advanced Settings page) you can browse your hard drive and select the folder you previously saved the file (HT8xfw.bin)



4. Click "Upload Firmware" and wait few minutes until the new program is loaded.

Grandstream SIP Phone HT812/HT814

the filename in URL for the firmware upgrade has been disabled on the latest firmware upgrade 1.0.43.11

## Upgrading via Local TFTP/HTTP/HTTPS/FTP/FTPS Servers

For users that would like to use remote upgrading without a local TFTP/FTP/FTPS/HTTP/HTTPS server, Grandstream offers a NAT-friendly HTTP server. This enables users to download the latest software upgrades for their devices via this server. Please refer to the webpage:

<https://www.grandstream.com/support/firmware>

Alternatively, users can download for example a free TFTP or HTTP server and conduct a local firmware upgrade. A free window version TFTP server is available for download from:

[http://www.solarwinds.com/products/freetools/free\\_tftp\\_server.aspx](http://www.solarwinds.com/products/freetools/free_tftp_server.aspx)

<http://tftpd32.jounin.net/>.

Instructions for local firmware upgrade via TFTP:

1. Unzip the firmware files and put all of them in the root directory of the TFTP server.
2. Connect the PC running the TFTP server and the phone to the same LAN segment.
3. Launch the TFTP server and go to the File menu->Configure->Security to change the TFTP server's default setting from **"Receive Only"** to **"Transmit Only"** for the firmware upgrade.
4. Start the TFTP server and configure the TFTP server in the phone's web configuration interface.
5. Configure the Firmware Server Path to the IP address of the PC.
6. Save and Apply the changes and reboot the HT812/HT814.

End users can also choose to download a free HTTP server from <http://httpd.apache.org/> or use Microsoft IIS web server.

## Firmware and Configuration File Prefix and Postfix

Firmware Prefix and Postfix allows device to download the firmware name with the matching Prefix and Postfix. This makes it possible to store all of the firmware with different version in one single directory. Similarly, Config File Prefix and Postfix allows device to download the configuration file with the matching Prefix and Postfix. Thus, multiple configuration files for the same device can be stored in one directory. In addition, when the field "Check New Firmware only when F/W pre/suffix changes" is set to "Yes", the device will only issue firmware upgrade request if there are changes in the firmware Prefix or Postfix.

## Managing Firmware and Configuration File Download

When "Automatic Upgrade" is set **"Yes, every"** the auto check will be done in the minute specified in this field. If set to **"daily at hour (0-23)"**, Service Provider can use P193 (Auto Check Interval) to have the devices do a daily check at the hour set in this field with either Firmware Server or Config Server. If set to **"weekly on day (0-6)"** the auto check will be done on the day specified in this field. This allows the device to periodically check if there are any new changes need to be taken on a scheduled time. By defining different intervals in P193 for different devices, Server Provider can spread the Firmware or Configuration File download in minutes to reduce the Firmware or Provisioning Server load at any given time

## Configuration File Download

Grandstream SIP Devices can be configured via the Web Interface as well as via a Configuration File (binary or XML) through TFTP, FTP/FTPS or HTTP/HTTPS. The **Config Server Path** is the TFTP or HTTP/HTTPS server path for the configuration file. It needs to be set to a valid URL, either in FQDN or IP address format. The **Config Server Path** can be the same or different from the **Firmware Server Path**.

A configuration parameter is associated with each particular field in the web configuration page. A parameter consists of a Capital letter P and 2 to 3 (Could be extended to 4 in the future) digit numeric numbers. i.e., P2 is associated with the "New Password" in the Web GUI->Maintenance->Web/SSH Access page->Admin Password. For a detailed parameter list, please refer to the corresponding firmware release configuration template.

When the HT812/HT814 boots up or reboots, it will send a request to download a file named "cfgxxxxxxxx" followed by a configuration XML file named "cfgxxxxxxxx.xml", where "xxxxxxxx" is the MAC address of the phone, i.e., "cfg000b820102ab" and "cfg000b820102ab.xml". If the download of "cfgxxxxxxxx.xml" file is not successful, the provision program will download a generic cfg.xml file and then download cfg<Model>.xml. The configuration file name should be in lower case letters.

HT818/HT814 supports DHCP option 67 allowing to provide custom name for the provisioning file. If DHCP option 67 is used, the following file download sequence will be applied:

Step 1: cfg<MAC>

Step 2: <option 67 bootfile> → cfg<MAC>.xml → cfg.xml → cfg<Model>.xml

### Notes:

1. Only XML or binary config file formats are accepted.
2. The MAC header in XML config file should be the device MAC or needs to be removed completely.




Figure 15: XML Config File – MAC Header

the filename in URL for config provision has been disabled on the latest firmware upgrade 1.0.43.11

## RESTORE FACTORY DEFAULT SETTINGS

### Warning

Restoring the Factory Default Settings will delete all configuration information on the phone. Please backup or print all the settings before you restore to the factory default settings. Grandstream is not responsible for restoring lost parameters and cannot connect your device to your VoIP service provider.

There are three (3) methods for resetting your unit:

### Using the Reset Button

To reset default factory settings using the reset button please follow the steps above:

1. Unplug the Ethernet cable.
2. Locate the reset hole on the back panel of your HT812/HT814.
3. Insert a pin in this hole, and press for about 7 seconds.
4. Take out the pin. All unit settings are restored to factory settings

### Using the IVR Command

Reset default factory settings using the IVR prompt:

1. Dial "\*\*\*\*" for voice prompt.
2. Enter "99" and wait for "reset" voice prompt.
3. Enter the encoded MAC address (Look below on how to encode MAC address).
4. Wait 15 seconds and device will automatically reboot and restore factory settings.

### Encode the MAC Address

1. Locate the MAC address of the device. It is the 12-digit HEX number on the bottom of the unit.
2. Key in the MAC address. Use the following mapping:

Key	Mapping
<b>0-9</b>	0-9
<b>A</b>	22 (press the "2" key twice, "A" will show on the LCD)
<b>B</b>	222
<b>C</b>	2222
<b>D</b>	33 (press the "3" key twice, "D" will show on the LCD)
<b>E</b>	333
<b>F</b>	3333

Table 12: MAC Address Key Mapping

For example: if the MAC address is 000b8200e395, it should be keyed in as "00022228200333395"

### Reset from Web Interface (Reset Type)

1. Access your HT812/HT814 UI by entering its IP address in your favorite browser.
2. Enter your admin password (default: admin).
3. Press **Login** to access your settings.
4. Go to **Basic Settings** → **Reset Type**
5. Press **Reset** button (after selecting the reset type).

• **Full Reset:** This will make a full reset

• **ISP Data:** This will reset only the basic settings, like IP mode, PPPoE and Web port

• **VoIP Data Reset:** This will reset only the data related with a service provider like SIP server, sip user ID, provisioning and others.

- Factory Reset will be disabled if the "Lock keypad update" is set to "Yes".

- If the HT812/HT814 were previously locked by your local service provider, pressing the RESET button will only restart the device. The device will continue to feature default settings.

## Reset using SIP NOTIFY

1. Access your HT812/HT814 UI by entering its IP address in your favorite browser.
2. Go to **Profile #** page.
3. Set "Allow SIP Factory Reset" to "Yes". (Default is No)
4. Once a SIP NOTIFY with "event: reset" is received, the ATA will perform factory reset.

Received SIP NOTIFY will be first challenged for authentication purpose before taking factory reset action. The authentication can be done either using admin credentials (if no SIP account is configured) or using SIP account credentials.

## CHANGE LOG

This section documents significant changes from previous versions of the admin guide for HT812/HT814. Only major new features or major document updates are listed here. Minor updates for corrections or editing are not documented here.

### Firmware Version 1.0.47.4

- Added IVR support to check Device Individual Certificate Information. [[Interactive Voice Prompt Response Menu](#)]
- Added support "https://" in Config Server Path field. [[Config Server Path](#)]
- Added support "https://" in Firmware Server Path field. [[Firmware Server Path](#)]
- Added support configure RFC2833 Events Count to 0, 0 means continuous RFC2833 events. [[RFC2833 Events Count](#)]
- Added support Inband DTMF TX Gain. [[Inband DTMF TX Gain](#)]
- Added support to disable the "CDR File Option". [[CDR File Option](#)]
- Added support Special Condition Tone. [[Call Progress Tones](#)]
- Added support Incoming Call Duration Limit. [[Incoming Call Duration Limit](#)]
- Added support "Port Voltage Off upon no SIP Registration or SIP Registration Failure" and "Delay Time of Port Voltage Off Timer Since Boot". [[Port Voltage Off Timer](#)]
- Added LAN Port VLAN Feature Under Bridge Mode on HT812 and HT814. [[LAN Port VLAN Feature Under Bridge Mode](#)]

### Firmware Version 1.0.45.2

- Added override config file option "cfgMAC\_override.xml". [[cfgMAC\\_override.xml](#)]
- Added option "Download and Process All Available Config File". [[Download and Process All Available Config Files](#)]
- Added option "When To Restart Session After Re-INVITE received" [[When To Restart Session After Re-INVITE received](#)]
- Updated the option in "Unregister On Reboot" to 0 – No, 1 – All, 2 – Instance. [[Unregister On Reboot](#)]

### Firmware Version 1.0.43.11

- Added Charter CA to the approved certificate list. [[Load CA Certificates](#)]
- Added support for TR-069 on the management interface. [[Enable TR-069 Through Management Interface](#)]
- Added ability to send Syslog traffic through Management Interface. [[Enable Syslog Through Management Interface](#)]
- Added support for variable on Provisioning link. [[Enable Using tags in URL](#)]
- Updated the default option of "Disable Reminder Ring for DND" to "Yes". [[Disable Reminder Ring for DND](#)]
- Add SSL Key Log File. [[With Secret Key Information](#)]
- Add Information Capture. [[Information Capture](#)]
- Allow configuring devices through SSH from different networks. [[Security Controls for SSH/Telnet Access](#)]
- Removed Telnet Idle Timeout Configuration Option. [[Telnet Idle Timeout](#)]
- Added additional Flash Digit events. [[Flash Digit Control](#)]
- Optimized the layout of the software version on the status page to make it look better.
- Add support of DHCP Option 150. [[Additional Override DHCP Option](#)]
- Merge DHCP Option 160 with DHCP Option 66. [[Allow DHCP Option 66 or 160 to Override Server](#)]
- Add a new special feature option "GIBTELECOM". [[Special Feature](#)]
- Add support for the "From Domain" option. [[From Domain](#)]
- GUI enhancement to display correctly port status.
- Added support for SRTP Key Length. [[SRTP Key Length](#)]
- Increased Admin/User/Viewer Password length to 30 characters. [[User/Viewer Password](#)] [[Admin Password](#)]
- Added support for Inband DTMF Duration. [[Inband DTMF Duration](#)]
- Added support for DSP DTMF Detector Duration Threshold. [[DSP DTMF Detector Duration Threshold](#)]
- Added new attribute values on WebUI:
  - TR-069 firewall rules (Value Range:1-65535, no default). [[TR-069 firewall rules](#)]
  - Root CA Version (0 – Current Root; 1 – New Root, default is 1) [[Root CA Version](#)]
  - Provision and upgrade to new Gen-2 certificate. (1- upgrade; 0 – no upgrade, default is 0). [[Gen-2 certificate](#).]
  - Contents (text string) of Gen-2 certificate to upgrade. (String. Max length 8192, no default). [[Gen-2 certificate](#).]
  - Contents (text string) of Gen-2 EC private key to upgrade. (String. Max length 8192, no default) [[Gen-2 EC private key](#)]
  - Disable filename in URL for config provision. [[Configuration File Download](#)]
  - Disable filename in URL for firmware upgrade. [[Firmware Upgrade procedure](#)]

### Firmware Version 1.0.41.2

- Updated Time Zone option "GMT+01:00 (Paris, Vienna, Warsaw)" to "GMT+01:00 (Paris, Vienna, Warsaw, Brussels)". [[Basic Settings Page Definitions](#)]

#### **Firmware Version 1.0.39.4**

- Added feature to send SNMP traffic through Management Interface. [[Basic Settings Page Definitions](#)]
- Added feature to re-subscribe only after a configurable timeout after receiving 403. [[Profiles Page Settings](#)]
- Added feature support e911 compliance and HELD protocol. [[Advanced Settings Page Definitions](#)]
- Updated the default value of "Maximum Number of SIP Request Retries" from 4 to 2. [[Profiles Page Settings](#)]
- Updated CDR File Option | SIP File Option (P8534/8535) value from "1 – Override" to "Overwrite". [[Advanced Settings Page Definitions](#)]
- Added Local IVR option that announces extension number of the port. [[Understanding HT812/HT814 Interactive Voice Prompt Response Menu](#)]

#### **Firmware version 1.0.37.1**

- Added feature Configuration File Types Allowed. [[Advanced Settings Page Definitions](#)].
- Added feature MAC in User-Agent [[Profile Page Definitions](#)]
- Added feature Use MAC Header [[Profile Page Definitions](#)]

#### **Firmware Version 1.0.35.4**

- Added support to allow HT8xx provision admin password without special characters.
- Added support for Israel time zone with DST.

#### **Firmware Version 1.0.33.4**

- Added feature Special Proceed Indication Tone. [Special Proceed Indication Tone].
- Added feature MWI Tone. [MWI Tone].

#### **Firmware Version 1.0.31.1**

- Added support to always send HTTP Basic Authentication Information. [[Always Send HTTP Basic Authentication Information](#)]
- Added support to Enable Call Waiting Alert-Info in 180 Ringing Response. [[Enable Call Waiting alert-info In 180 Ringing Response](#)]

#### **Firmware Version 1.0.29.8**

- Added support to authenticate based on OpenVPN Username and OpenVPN Password. [OpenVPN Username and OpenVPN Password]
- Added feature "OnHook DC Feed Current" [OnHOOK DC Feed Current]

#### **Firmware Version 1.0.27.2**

- No Major Changes

#### **Firmware Version 1.0.25.5**

- Added support for "OpenVPN". [OpenVPN]
- Added support of "Maximum Number of SIP Request Retries". [Maximum Number of SIP Request Retries]
- Added support for "Failback Timer". [Failback Timer]

#### **Firmware Version 1.0.23.5**

- Added Special Feature IZZI to support N-Way conference hosted on Nokia IMS.
- Added support for "DNS SRV Failover Mode". [DNS SRV Failover Mode]
- Added support of "Register before DNS SRV Failover". [Register before DNS SRV Failover]

#### **Firmware Version 1.0.21.4**

- Added support for IPv6 address without square brackets. [Primary SIP Server][Failover SIP Server][Outbound Proxy] [Backup Outbound Proxy]
- Added support for DHCP Domain Name configuration. [DHCP domain name]
- Added support of "Use Configured IP" for "DNS Mode". [Use Configured IP]
- Added support for "Play Busy Tone When Account is unregistered". [Play Busy Tone When Account is unregistered]

#### **Firmware Version 1.0.19.11**

- Added "Disable" option for "Web Access Mode" feature. [Web Access Mode]
- Moved "Trusted CA certificates" from ProfileX to Advanced Settings and renamed as Trusted CA Certificates A and Trusted CA Certificates B. [Trusted CA Certificates (A,B)]
- Added feature "Disable User Level Web Access" and "Disable Viewer Level Web Access". [Disable User Level Web Access] [Disable Viewer Level Web Access]
- Added feature "Use P-Asserted-Identity Header". [Use P-Asserted-Identity Header]
- Added feature "Load CA Certificates". [Load CA Certificate]
- Added support to configure TR-069 connection request port. [Connection Request Port]
- Added OI\_BR to special feature. [Special Feature]
- Added New Zealand Standard for Pulse Dialing Standard. [ Pulse Dialing Standard]
- Added support to set Ring Timeout to 0 for unlimited ring timeout. [Ring Timeout]
- Increased "SIP TLS Certificate" and "SIP TLS Private Key" supported maximum length from 2048 to 4096. [SIP TLS Certificate][SIP TLS Private Key]

#### Firmware Version 1.0.17.5

- Added feature "Maximum TLS Version". [Maximum TLS Version]
- Updated "São Paulo" time zone to UTC-3. [Time Zone]

#### Firmware Version 1.0.15.4

- Added more choices to feature "Disable Weak TLS Ciphers". [Disable Weak TLS Cipher Suites]
- Added feature "Syslog Protocol". [[Syslog Protocol](#)]
- Added support for "Distinctive Call Waiting Tone". [Distinctive Call Waiting Tone]
- Added support for "Call Waiting Tones". [Call Waiting Tones]
- Added support for DHCP option 67. [Configuration File Download]
- Added support to allow CID name fields for ports that are part of the active hunting group to take effect. [Hunting Group]
- Added support for GDMS. [ACS URL]

#### Firmware Version 1.0.13.7

- Added ability to support provisioning server path containing the server authentication credentials for the DHCP option 66. [Allow DHCP Option 66 to Override Server]
- Added support to send SNMP trap to 3 different servers. [SNMP Trap IP Address]
- Added feature "Call Features Settings". [Call Features Settings]
- Added feature "Use SIP User Agent". [SIP User-Agent]
- Updated "Use SIP User Agent Header" to "SIP User Agent Postfix". [[SIP User Agent Postfix](#)].
- Added feature "Disable Reminder Ring for DND". [Disable Reminder Ring for DND]
- Added feature "CDR File Option". [CDR File Option]
- Added feature "SIP File Option". [SIP File Option]
- Added feature "Disable Weak TLS Cipher Suites". [Disable Weak TLS Cipher Suites]
- Added feature "Pulse Dialing Standard". [Pulse Dialing Standard]
- Added feature "Callee Flash to 3WC". [Callee Flash to 3WC]
- Added feature "RFC2833 Count". [RFC2833 Events Count] [RFC2833 End Events Count]
- Added feature "Replace Beginning '+' with 00 in Caller ID". [Replace Beginning '+' with 00 in Caller ID]
- Added feature "Reset Call Features". [Reset Call Features]
- Added support to view, download, and delete the call history through device Web UI. [CDR File]
- Added support to store SIP file locally. [SIP File]

#### Firmware Version 1.0.11.6

- Added "CPU Load" on Web UI status page [CPU Load]
- Added support for SIP keep-alive to use SIP NOTIFY. [Enable SIP OPTIONS/NOTIFY Keep Alive]
- Added feature "Network Cable Status" on Web UI status page. [Network Cable Status]
- Added support for Management Interface. [Management Interface]
- Added feature "SSH Idle Timeout". [SSH Idle Timeout]
- Added feature "Telnet Idle Timeout". [Telnet Idle Timeout]
- Added feature "Use ARP to detect network connectivity". [Use ARP to detect network connectivity]
- Added feature "Call Record".

#### Firmware Version 1.0.10.6

- Added feature "Inband DTMF Duration". [Inband DTMF Duration]
- Added feature "RFC2543 Hold". [RFC2543 Hold]
- Added feature "Visual MWI Type". [[Visual MWI Type](#)]
- Added feature "Disable Unknown Caller ID". [Disable Unknown Caller ID]
- Added feature "Disable # as Redial Key". [Disable # as Redial Key]
- Added feature "Ring Frequency". [Ring Frequency]
- Added feature "Allow SIP Factory Reset". [Allow SIP Factory Reset] [Reset using SIP NOTIFY]
- Added support for G722 Codec. [HT812/HT814 Technical Specifications]
- Added support to allow user to choose preference codec from PCMU and PCMA for FAX pass-through codec. [Fax Mode]
- Added Web menu in Spanish. [Language]

#### Firmware Version 1.0.9.3

- Added feature "Custom Certificate". [Custom Certificate]
- Added feature "Use P-Access-Network-Info Header". [Use P-Access-Network-Info Header]
- Added feature "Use P-Emergency-Info Header". [Use P-Emergency-Info Header]
- Added feature "Conference Party Hangup Tone" when "Special Feature" is set to MTS. [Call Progress Tones]
- Add support for HTTPS based on TLS v1.2

#### Firmware Version 1.0.8.7

- Added [CenturyLink, MTS] to Special Feature.
- Added support for Russian in Web UI and IVR. [Language]
- Added support for upgrade device via FTP/FTPS server. [UPGRADING AND PROVISIONING]
- Added support to have the call waiting tone through SIP INFO.
- Added support for Hunting Group on HT812 Web UI.

- Added feature "Validate Server Certificates". [Validate Server Certificates]

◦ Added feature [Blacklist for Incoming Calls]. [Blacklist for Incoming Calls]

- Added support for [Telnet]
- Added feature [Play busy/reorder tone before Loop Current Disconnect]

#### Firmware Version 1.0.5.11

- Changed default "Upgrade Via" from HTTP to HTTPS. [Upgrade via] [Upgrade Protocol] [UPGRADE PROTOCOL] [UPGRADING AND PROVISIONING]
- Added the ability to schedule [Automatic Reboot]
- Added support for [SNMPv3]
- Added support for 3 level access through RADIUS authorization (Admin, User and [viewer])
- Added option to customize number of failed [Web Access Attempt Limit] to access web GUI
- Added option to customize idle time to logout the web access with [Web Session Timeout]
- Added option to disable WAN side ports [Black List for WAN Side Port]
- Added feature "Caller ID Fetch Order" option under FXS port settings. [Caller ID Fetch Order]
- Added feature "Enable High Ring Power" option under FXS port settings. [Enable High Ring Power]
- Added feature "Internet Protocol" to choose from "IPv4 Only", "IPv6 Only", "Both, prefer IPv4", "Both, prefer IPv6". [Internet Protocol]
- Added feature "IPv6 Address" to configure IPv6 Address. [IPv6 Address]

#### Firmware Version 1.0.3.7

- Added option "Use Actual Ephemeral Port in Contact with TCP/TLS" to force device to use actual ephemeral port. [Use Actual Ephemeral Port in Contact with TCP/TLS]
- Added option "SIP URI Scheme When Using TLS" to choose between 'SIP' and 'SIPS'. [SIP URI Scheme When Using TLS]
- Added Option "Backup Outbound Proxy" to use backup Outbound Proxy if Outbound Proxy registration expires. [Backup Outbound Proxy]
- Added option "Prefer Primary Outbound Proxy" to enable registration through primary outbound proxy if registration expires. [Prefer Primary Outbound Proxy]
- Added option "Enable RTCP" to enable RTCP function through Web UI. [Enable RTCP]
- Added option "Hold Target Before Refer" to enable device to hold before being referred. [Hold Target Before Refer]
- Added Option "Enable Session Timer" to disable session timer. [Enable Session Timer]
- Added feature "Conference URI" to support Conference URI. [Conference URI]
- Added feature "White List for WAN Side" for remote management. [White List for WAN Side]
- Added feature "Black List for WAN Side" for remote management. [Black List for WAN Side]
- Added option "Web Access Mode" to choose between "HTTPS" and "HTTP" to access device Web UI. [Web Access Mode]
- Added feature "HTTPS Web Port" to set HTTPS web port instead of using default HTTPS port. [HTTPS Web Port]
- Added feature "SSH Port" to self-configure SSH port. [SSH Port]
- Added SNMP related features.

#### Firmware Version 1.0.3.2

- Added option "DNS SRV use Registered IP" to force DNS SRV to use registered IP instead of use first SRV. [DNS SRV use Registered IP]
- Changed default NTP server from us.pool.ntp to pool.ntp.org.

#### Firmware Version 1.0.2.7

- No major changes

#### Firmware Version 1.0.2.5

- Changed OPUS Payload Type default value to 123 to match other GS products. [OPUS Payload Type]

#### Firmware Version 1.0.2.3

- Added network check mechanism to enable or disable WAN port web access.
- Added a re-enter box to confirm change user and admin password on web GUI to avoid typo or mistakes. [Confirm End User Password] [Confirm Admin Password]

#### Firmware Version 1.0.2.1

- This is the initial version for HT812/HT814.

#### Need Support?

Can't find the answer you're looking for? Don't worry we're here to help!

[CONTACT SUPPORT](#)